



Title <i><b>Ravage - 3-Wire ISCV Driver</b></i>			Drawn By: <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0.2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:07 p.m.</b>	Sheet of		
File: <b>C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\3-Wire ISCV Driver.SchDoc</b>				



1

2

3

4

A









B

C

D

Title <b><i>Ravage - Connectors</i></b>			<i>Drawn By:</i> <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0,2</b>		
Date: 20/09/2011      Time: 6:37:07 p.m.      Sheet    of				
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Connector.SchDoc				





A

A

B

B




C


C









D


D


All inputs 12V capable.




Title <i><b>Ravage - Digital Inputs</b></i>			Drawn By: <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0.2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:07 p.m.</b>	Sheet of	File: <b>C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Digital Inputs.SchDoc</b>	



Title <i><b>Ravage - Analog Inputs 8-15</b></i>			<i>Drawn By: Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0.2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:08 p.m.</b>	Sheet of		
File: <b>C:\Users\el_presto\Desktop\WorkSpace\FreeEMS\Preston-Ravage\Ravage\Extra Analogue Inputs.SchDoc</b>				



Title <b><i>Ravage - Igniter Outputs</i></b>			Drawn By: <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0.2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:08 p.m.</b>	Sheet <b>of</b>		
File: <b>C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Igniter Outputs.SchDoc</b>				







A

B

C






D


A


B

C

D



Title <b><i>Ravage - Low Side Drivers</i></b>			Drawn By: <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0,2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:08 p.m.</b>	Sheet <b>of</b>	File: <b>C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Low Side Drivers.SchDoc</b>	



A

B

C


D


A

B

C

D



Title <i><b>Ravage - RS232 Comms</b></i>			Drawn By: <i>Dan Visser</i>	
Size: <b>A4</b>	Number: <b>A</b>	Revision: <b>0.2</b>		
Date: <b>20/09/2011</b>	Time: <b>6:37:09 p.m.</b>	Sheet of		
File: <b>C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\RS232 Comms.SchDoc</b>				





