

Title <i>Ravage - Extra Analogue Inputs</i>			Drawn By: <i>Dan Visser</i>	
Size: A4	Number: A	Revision: 0.2		
Date: 25/09/2011 Time: 11:49:11 a.m. Sheet 6 of 13				
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Extra Analogue Inputs.SchDoc				

A

B

C


D


A


B


C







D



Title <i>Ravage - Digital Inputs</i>			Drawn By: <i>Dan Visser</i>		
Size: A4	Number: A	Revision: 0.2			
Date: 25/09/2011 Time: 11:49:12 a.m. Sheet 7 of 13					
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Digital Inputs.SchDoc					



Title <i>Ravage - Igniter Outputs</i>			<i>Drawn By: Dan Visser</i>	
Size: A4	Number: A	Revision: 0,2		
Date: 25/09/2011 Time: 11:49:12 a.m. Sheet 9 of 13				
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Igniter Outputs.SchDoc				



A

B

C






D


A


B

C

D



Title <i>Ravage - Low Side Drivers</i>			Drawn By: <i>Dan Visser</i>		
Size: A4	Number: A	Revision: 0,2			
Date: 25/09/2011 Time: 11:49:12 a.m. Sheet 11 of 13					
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Low Side Drivers.SchDoc					



Title

Size: A4

Date: 25/09/2011

Number: A

Time: 11:49:12 a.m.

File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Connector.SchDoc

Revision:0,2

Sheet 13 of 13

Drawn By:

Dan Visser

Altium