



PLEATED PUFFY CROSS

Start with a Bird Base.


A 10
F 30
B 2000




① VF




② F-UF to crease.



③ a) F-UF crease to horizon.
b) VF tip to crease



④ VF tip to edge.




⑤ Pleat: VF on creases + MF between, ending at horizon.



3-D view.




⑦ Spread the vane evenly.




⑧ Repeat steps 1-5 on the three remaining flaps.

⑧ Underneath, carefully poke a small finger into hole + spread the paper. Reach into each vane to puff it out.



⑨ View from below. Spread pleats out a bit + flip cross over.



Try it! It looks better than this drawing suggests.