


Aerospace Village Badge 2022


Warning SAO Assembly

Components:


- SAO Male Connector
- x2 1K Ohm resistors
- x2 Red LEDs



1. Solder the resistors to their respective pads. Note: Orientation does not matter for the resistors
2. Orient the red LEDs so that the circles on the PCB and LED are adjacent to one another and then solder the LEDs in place.




LEDs in correct orientation



Observe the orientation markings

3. Using the SAO jig solder the connector to the back of the PCB.



4. Ensure correct operation.