

Prerequisites to use this driver :

There is only one thing you need to do before start use this library so You need to download also GPIO driver then copy these files in your project folder .

First include
DHT11.h in main.c

```
graph TD; A([First include DHT11.h in main.c]) --> B([Then in main file define DHT11_Handler_t and then configure your sensor GPIO Pin]); B --> C([Then in while one just call DHT_GET_Measurements(). Function and read the status if not DHT11_ERROR then your handler now hold the measured value]);
```

Then in main file define
`DHT11_Handler_t` and
then configure your
sensor GPIO Pin

Then in while one just call
`DHT_GET_Measurements()`.
Function and read the status if not
`DHT11_ERROR` then your handler
now hold the measured value