


# PowerSheet




File: PowerSheet.kicad\_sch


# Experiment



File: Experiment.kicad\_sch



On PCB, with connector on left side, top-down,  
Pin 1 is top-right corner







- H101 MountingHole
- H102 MountingHole
- H103 MountingHole
- H104 MountingHole

Sheet: /  
File: BIRDS-X-PCB.kicad\_sch

## Title:

Size: USLetter Date:  
KiCad E.D.A. kicad 7.0.2

Rev:  
Id: 1/4





Sheet: /PowerSheet/  
File: PowerSheet.kicad\_sch

**Title:**

Size: USLetter Date:  
KiCad E.D.A. kicad 7.0.2

**Rev:**  
Id: 2/4





Sheet: /MicrocontrollerSheet/  
File: MicrocontrollerSheet.kicad\_sch

# Title:

Size: USLetter Date:  
KiCad E.D.A. kicad 7.0.2

Rev:  
Id: 4/4