

PowerSheet




File: PowerSheet.kicad_sch

Experiment



File: Experiment.kicad_sch


MicrocontrollerSheet




File: MicrocontrollerSheet.kicad_sch


TODO add thermometers near all radfets

On PCB, with connector on left side,
Pin 1 is top-right corner



Sheet: /		
File: BIRDS-X-PCB.kicad_sch		
Title:		
Size: USLetter	Date:	Rev:
KiCad E.D.A. kicad 7.0.1		Id: 1/4





Sheet: /Experiment/ File: Experiment.kicad_sch		
Title:		
Size: USLetter	Date:	Rev:
KiCad E.D.A. kicad 7.0.1	Id: 3/4	

