



eastman



**18X12W LED 6IN1 WATERPROOF PAR LIGHT**

# Technical Data and Features

## Product Features

Control panel : 4 Digital LED display figures

Beam angle : 25°

Power Control mode : sound activation, auto, master/slave, DMX-512

DMX channels : 6/ 10 CHS

Dimmer : 0-100% with regulated constant color control

Working environment : up to 40°C

## Technical Data

Power supply : AC100-240V, 50Hz/60Hz

Power consumption : 180W

Light source :

18x12W (RGBWAP 6 IN 1) LED

Protection rate : IP65

Dimension size : 260x260x355mm

Packing size : 250x250x305mm,  
520x520x325mm(4 pcs)

## Menu Function Settings

### DIGITAL SHOW FUNCTION FORM

No	Show	Function	Value	Instruction
1	<b>d001</b>	DMX address	001~512	6CH mode, UP/DOWN change the value,
2	<b>A001</b>	DMX address	001~512	10CH mode, UP/DOWN change the value,
3	<b>r255</b>	Red dim	000~255	UP/DOWN adjust brightness
4	<b>G255</b>	Green dim	000~255	UP/DOWN adjust brightness
5	<b>b255</b>	Blue dim	000~255	UP/DOWN adjust brightness s
6	<b>u255</b>	White dim	000~255	UP/DOWN adjust brightness
7	<b>y255</b>	Amber dim	000~255	UP/DOWN adjust brightness
8	<b>P255</b>	UV dim	000~255	UP/DOWN adjust brightness
9	<b>FH99</b>	Strobe	01 ~ 99	UP/DOWN adjust brightness
10	<b>CL01</b>	Colors choose	01 ~ 08	UP/DOWN Change color
11	<b>CC99</b>	Colors Jump	01 ~ 99	UP/DOWN adjust brightness
12	<b>DE99</b>	Colors Gradate	01 ~ 99	UP/DOWN adjust brightness
13	<b>CP99</b>	Colors Pulse	01 ~ 99	UP/DOWN adjust brightness
14	<b>SU01</b>	Colors sound-Active	01~09	UP/DOWN Change the effects

# DMX512 Channel


## DMX MODE

### 6 Channels Mode

Channel	Function	Instruction
CH1	R Dimmer	Red Dimmer- Dark to Bright
CH2	G Dimmer	Green Dimmer- Dark to Bright
CH3	B Dimmer	Blue Dimmer- Dark to Bright
CH4	W Dimmer	White Dimmer- Dark to Bright
CH5	A Dimmer	Amber- Dark to Bright
CH6	UV Dimmer	Purple- Dark to Bright

### 10 Channels Mode

Channel	Function	Instruction
CH1	Total Dimmer	Total Dimmer- Dark to Bright
CH2	R Dimmer	Red Dimmer- Dark to Bright
CH3	G Dimmer	Green Dimmer- Dark to Bright
CH4	B Dimmer	Blue Dimmer- Dark to Bright
CH5	W Dimmer	White Dimmer- Dark to Bright
CH6	A Dimmer	Amber- Dark to Bright
CH7	UV Dimmer	Purple- Dark to Bright
CH8	Total Strobe	Total Flash Strobe- Slow to Fast
CH9	Function Choice	000~050: CH1-CH8 Control. 051~100: Different Colors output 101~150: Colors Jump Change. 151~200: Colors Gradate. 201~250: Colors Pulse Change. 251~255: Sound-Active
CH10	Function/Speed	Slow to Fast (At the Colors output and sound choose the color)



eastman

[info@eastmanlighting.com](mailto:info@eastmanlighting.com)