



The pads and traces in red represent the RF net.

They should be matched to 50 ohms controlled impedance.