

Ethernet

Ethernet.sch

RF Frontend

RFFrontend.sch

Input Output

InputOutput.sch

Clock

Clock.sch

Power

Power.sch

KF70 Steve Haynal

SofterHardware

Sheet: /

File: hermeslite.sch


Title: **Hermes-Lite**

Size: USLetter | Date: 2016-02-18

KiCad E.D.A. kicad 4.0.1-stable

Rev: **2.0-pre1**

Id: 1/6



KF70 Steve Haynal

SofterHardware

Sheet: /Ethernet/

File: Ethernet.sch

**Title: Ethernet**


Size: USLetter Date: 2016-04-03

KiCad E.D.A. kicad 4.0.1-stable

**Rev: 2.0-pre1**

Id: 2/6







To facilitate build options, there are 5 slightly enlarged SMT pads prefixed WJ (wire jumper) to ease soldering a small wire jumper to:

WJ1 R25 pad  
WJ2 Test point pad  
WJ3 C60 pad  
WJ4 C63 pad  
WJ5 JP2 pad

See BOM "Clock Build Options" sheet for build details



KF70 Steve Haynal

SofterHardware

Sheet: /Clock/

File: Clock.sch


**Title: Clock**

Size: USLetter Date: 2016-04-03

KiCad E.D.A. kicad 4.0.1-stable

Rev: 2.0-pre1

Id: 4/6



KF70 Steve Haynal

SofterHardware

Sheet: /Power/

File: Power.sch

**Title: Power**

Size: USLetter Date: 2016-04-03

KiCad E.D.A. kicad 4.0.1-stable

Rev: 2.0-pre1

Id: 5/6

