
Troubleshoot with Revit Survey Point2


Created On: February 24, 2023

Created with:
dominKnow Capture
<https://www.dominknow.com>

1. Click on the 'View' tab in the ribbon




2. Click on the Visibility / Graphics button to open the settings




3. Click on the + box to the left of 'Site' to open this section up




4. Check off the box for Survey Point to toggle it on



5. Press button: **Apply**



6. Press button: OK



7. Select the Survey Point



8. Left click on the N/S coordinate set to edit it




9. Click on the opened coordinate editor, Type: **0** Press Enter



10. Left click on the /S coordinate set to edit it



11. Click on the opened coordinate editor, Type: **0** Press Enter



12. Click on the clip to the left of the Survey Point to clip the Survey Point to (0,0,0)



13. Select and start to drag the Survey Point with your left mouse button



14. Finish drag and drop on the buildings bottom left corner



15. Steps completed