




GOOD DIRECTIONS, INC.

ASSEMBLY INSTRUCTIONS

FULL SIZE WEATHERVANES

(with retaining hook)

COPPER SPACER BALL
(SMALL)



BRASS DIRECTIONALS


COPPER BALL (LARGE)



YOUR PACKAGE
INCLUDES THE
FOLLOWING PIECES:

- 1 Figure
- 1 Large Copper Ball
- 1 Set of Brass Directionals
- 1 Brass Ring
- 1 Small Steel Threaded Rod
- 1 Large Steel Rod (18")
- 1 Retaining Hook
- 1 Tube of Loctite®

SMALL ROD




BRASS
RING

LARGE
ROD (18")


ASSEMBLED
VIEW

1



POSITION
BRASS RING
OVER LARGE
ROD. TIGHTEN
SET SCREW

2




APPLY A LINE
OF LOCTITE® (supplied)
ACROSS THE THREADS.
(This small amount is
all that's needed)

THREAD SMALL ROD
INTO LARGE ROD.
POSITION WRENCHES
ON FLAT SPOTS.
TIGHTEN FIRMLY.

TIP: You may
save the remaining
LOCTITE® for other
uses. Simply
reverse the cap
for storage


3

SLIDE
LARGE
BALL
DOWN
ROD TO
BRASS
RING.



4

INTERLOCK
DIRECTIONALS.
SLIDE ONTO ROD.
TIGHTEN SET
SCREWS



(WEST GOES LEFT
OF NORTH)

5

APPLY COMMON
GREASE TO ROD
SO VANE WILL
ROTATE FREELY.

SLIDE WEATHERVANE
AND RETAINING HOOK ONTO
SMALL ROD SIMULTANEOUSLY.
TIGHTEN SET SCREW.

Brass bottom
of weathervane

Retaining hook.

