

User Manual - Smart Home Speaker

Introduction

- Thank you for purchasing the Smart Home Speaker.
- This device allows voice control for music, weather, and smart home devices.

Setup Instructions

- Plug the device into a power source.
- Download the companion mobile app.
- Connect the speaker to Wi-Fi via the app.

Troubleshooting

- Restart the device if unresponsive.
- Ensure Wi-Fi connection is stable.
- Reset device by holding the power button for 10 seconds.