



Knowledge Tip

How to Reset the Canon Printer Password

Document Approver: Rick Dadez

Reviewer: Sumit Kumar

Author: Amar Patil

Document number: QP-RS-KA-40

Date of Release: 10th August 2022



Table of Content

1.Process for How to Reset Admin Password on Canon Imagerunner ADV Printer.....	Error!
---------------------------------------------------------------------------------	--------

Bookmark not defined.



Review & Approval Record

Rev No	Date	Reason of Issue	Prepared By	Reviewed By	Approved By	Details of Amendments and revisions
1	08/10/2022	New	Saleem Patel	Sumit Kumar	Rick Dadez	New Version - 1.0

Amendment Record / Control Sheet (ACS)

Rev No	Date	Reason of Issue	Prepared By	Reviewed By	Approved By	Details of Amendments and revisions

Document Approvers

Document approval is maintained in the repository and can be found at:

Title or Role	Approver Name
Document Owner	Amar Patil
Document Reviewer	Sumit Kumar
Document Approver	Rick Dadez

Document Review Plans

Necessary reviews and updates to this document are defined below:

- The document will be reviewed on Yearly basis, or as and when required
- As required to correct or enhance information content

How to Find the Latest Revision of this Document


The latest revision of this document may be obtained as follows: Shared Drive and Teams folder

Document Distribution and Notification


Printed copies are for reference only and are not controlled. The user is responsible to work only from the current document revision.

Process for How to Reset the password for Canon ADV Printer



1. Go to printer Machine.
2. Press the **Settings/ Registration**




3. Press the **2 and 8 numerical key** on printer Simultaneously and then click **Settings/ Registration**



4. After than below options / Screen will appear then click on **Mode List** and then press the **Copier**




5. Press the **Functions** button and the click to **CLEAR** option





6. Then click **PWD-CLR** then click on **OK**



7. Then Click on **Reset (3)** Button three Times



8. Power off the printer and power on again and confirm.

End of Document