

Le Strum

Quick reference rev 4

Chord button function when **mode** held

Preset

Command

Global

Toggle
double blink on
single blink off

C	C#	D	D#	E	F	F#	G	G#	A	A#	B	
Basic Strum Mode		Guitar Chord Strum		Guitar Chord Sustain	Organ Buttons		Organ buttons with adds		Organ buttons w/ adds/retrig		Load user patch	maj
Start note on contact make	Start note on contact break	Use guitar chord voicing	Enable adds (sus4 add6/add9)	Sustain till change of chord	Chromatic scale on pads		Play chord on MIDI channel 2	Sustain ch.2 chord till change		Reverse pad layout	Save user patch	min
Stop note on contact make	Stop note on contact break	Guitar voicing upper oct.	Include guitar bass notes	Sustain common notes	Diatonic scale on pads	Pentatonic scale on pads		Sustain common notes ch.2		Circle of fifths chord layout	MIDI panic (all notes off)	7th
C#	G#	D#	A#	F	C	G	D	A	E	B	F#	

Chord Button Combinations

maj	7th	major 7th chord	maj	min	diminished chord	
min	7th	minor 7th chord	maj	min	7th	augmented chord

Added Notes (while holding a chord)

Top row chord button to right	sus4
Mid row chord button to right	add6
Bottom row chord button to right	add2/9

Other Features

mode + touch pad	Set midi note velocity
mode at startup	Reset settings / display version