



Stand

Glue this end to the
back of the base board.

Arduino (NG)

mount on the back.

Drill for spacer

threads or screws

Glue the stand in this area on the back,
make sure that the lower edges are flush.

Base board: Cut at outlines, sand and drill the
marked holes for your LEDs (3mm or 5mm)