


Spindle Mount Assembly:
The typical spindle is a high-speed rotary tool (Dremel™ or clone). There are a number of alternative tools and mount possibilities. Please see the wiki for details.

Shapeoko Build Instructions


STEP 10

http://www.shapeoko.com/wiki/index.php/Assembly_step_10



ITEM	QTY	PART NUMBER	TITLE
1	2	SM-TM1	Spindle Mount
2	4	SM-H11	Insertion Nut
3	4	SM-H07	M5 x 10mm SHCS
4	8	SM-H03	M5 Flat Washer
5	2	SM-TM2	Spindle Strap
6	4	SM-H09	M5 x 55mm SHCS
7	8	SM-H02	3/4" Nylon Spacer
8	1	SM-TM3	Rotary Tool



OPEN HARDWARE Attribution-ShareAlike 3.0 Unported (CC BY-SA 3.0)			
TOLERANCES (EXCEPT AS NOTED) BETWEEN FINISHED SURFACES FRACTIONAL: ± 1/64" DECIMAL: ± .010" DETAIL DIMENSIONS: ± 1/16"		DESIGNED BY: ERF	DATE: 6/5/2012
		TITLE Z Axis Spindle Assembly	
SCALE		SIZE B	DRAWING NUMBER SM-ZA03
		SHEET 1 OF 1	