

$$\begin{aligned} \text{ProtIFI Zn} \\ y = 0.265 + 0.353x_1 + 0.474x_2 + 0.363x_3 \\ R = 0.582 \end{aligned}$$

$$\begin{aligned} \text{ProtIFI Om} \\ y = 2.361 + 0.085x_1 + 0.124x_2 + 0.245x_3 \\ R = 0.546 \end{aligned}$$

$$\begin{aligned} \text{TECAN Zn} \\ y = 0.003 + 1.352x_1 + 3.224x_2 + 0.408x_3 \\ R = 0.665 \end{aligned}$$

$$\begin{aligned} \text{TECAN Om} \\ y = 0.657 + 0.173x_1 + 0.373x_2 + 0.280x_3 \\ R = 0.246 \end{aligned}$$

$$\begin{aligned} \text{Thermo Zn} \\ y = 1.137 + 0.230x_1 + 0.503x_2 + 0.154x_3 \\ R = 0.866 \end{aligned}$$

$$\begin{aligned} \text{Thermo Om} \\ y = 1.043 + 0.333x_1 + 0.289x_2 + 0.146x_3 \\ R = 0.887 \end{aligned}$$

$$\begin{aligned} \text{Waters Zn} \\ y = 1.394 + 0.633x_1 + 0.100x_2 + 0.174x_3 \\ R = 0.815 \end{aligned}$$

$$\begin{aligned} \text{Waters Om} \\ y = 1.163 + 0.497x_1 + 0.057x_2 + 0.164x_3 \\ R = 0.471 \end{aligned}$$