

GENERAL

Operational Hours

ATS Hours: 0400-1600; other times PPR before 1300.

AD ADMIN Hours: MON-FRI 0600-1445, other times O/R, EXC HOL.

Airport Information

RFF: CAT 7 H24; up to CAT 9 AVBL O/R.

PCN: RWY 02/20: 59/F/A/W/T

Customs: See ADMIN Hours

Operation

RWY Restriction

First 60m / 197ft at either end is provided as blast pad areas and shall not be used.

Taxi/Parking

Use MNM PWR when leaving stand.

Follow-me AVBL O/R.

All code letter E ACFT when taxiing via TWY B to C or A will be provided with wing tip marshal.

Standard Taxi Routes

Entry stands A1, A2:

- TWY A: proceed following guidance lines, pass stand signs, proceed straight ahead and turn right at A1 or A2 or as per ATC instructions.
- TWY C: proceed following guidance lines, turn left at TWY D or B and proceed straight ahead to turn right at TWY A, to continue ahead and make a right turn at A1 or A2 or as per ATC instructions.

Exit stands A1, A2:

- Stand A1: immediately turn right and right again at TWY B then left at TWY A to HLDG point of RWY or at TWY B turn left and right at TWY C to HLDG point.
- Stand A2: immediately turn right and right again at TWY B with wing walker if other ACFT parked on Stand A1, then left at TWY A to HLDG point of RWY or at TWY B turn left and right at TWY C to HLDG point.

Entry stands A3-A5:

- TWY A: proceed following guidance lines, turn right at TWY D or B. When using TWY D, continue and turn left at TWY C and left again at TWY B, follow taxi lanes to stand until abeam STOP indicator on port side.
- TWY C: proceed straight ahead turn left at TWY D or B. When using TWY D, continue straight ahead and turn right at TWY A and right again after passing the stand signs on surface at TWY B, follow taxi lanes to stand until abeam STOP indicator on port side.

Exit stands A3-A5:

- Stands A3-A5: immediately turn right and proceed straight ahead to TWY C to RWY HLDG PSN, or immediately turn right and right again on TWY B, follow guidance lane to turn left at TWY A to RWY HLDG PSN.

Warnings

Use of Nav aids facilities for LDG only permitted during ATS HR.


Stray animals on the movement area.

Birds in vicinity of AD.

DEPARTURE

Take-off Minima

RWY		02/20	
All ACFT	ft - m/km	0 - 400V	HJ only
		0 - 800V	HN




E031°42.5'

E031°43'

Sikhuphe TWR 118.550 0400-1600
Sikhuphe GND 121.800 RAD, HR by NOTAM

20
199°
1085

HS1 - Hold B1 to Alpha TWY may not be visible from ATC. Pilots to exercise caution and confirm taxi instructions with additional position reports when requested by ATC.



ARP
S 26 21.5
E 031 43.0

3580 X 45



FIRE STATION

RWY	TORA	ASDA	TODA
02	3580	3580	4690
20	3580	3580	3990

Warning:
When entering from TWY B or C onto the southern entry point, make a left turn onto B. Do not taxi beyond the No Entry signs.


COORDINATES

A1	S26 20.9	E031 43.2
A2	S26 20.9	E031 43.3
A3	S26 21.0	E031 43.2
A4, A5	S26 21.0	E031 43.3



VAR 20° W
MAG UP
AD ELEV 1092

02
019°
1092



SHO-FDSK

DEPARTURES RWY 20

4-10


DEPARTURES RWY 02

SID

SID

DEPARTURES RWY 20

DEPARTURES RWY 02



Changes: Country name

© Lido 2018

06-SEP-2018
SHO-FDSK

Eswatini **Manzini** King Mswati III/Sikhuphe Intl

4-20


DEPARTURES RWY 20

SID

SID

King Mswati III/Sikhuphe Intl **Manzini** Eswatini

DEPARTURES RWY 20



Changes: Country name

SHO-FDSK

5-10

DEPARTURES RWY 02**ALENI / DUKRA / GERAX / OKSAD / ORNAD / TONKA**

RWY 02 (019°)

When instructed, contact Sikhuphe APP.

DESIGNATOR	ROUTING	ALTITUDES
	Runway 02	
ALENI 128.000	at MNM 4000 RT direct ALENI	
DUKRA 128.000	at MNM 4000 or D3 VSK , whichever is earlier, LT HDG 290° - direct DUKRA	
GERAX 128.000	at MNM 4000 RT direct GERAX	
OKSAD 128.000	at MNM 4000 or D3 VSK , whichever is earlier, LT direct OKSAD	
ORNAD 128.000	at MNM 4000 RT direct ORNAD	
TONKA 128.000	at MNM 4000 RT direct TONKA	

06-SEP-2018

Eswatini **Manzini** King Mswati III/Sikhuphe Intl**SHO-FDSK****5-20****DEPARTURES RWY 20****SIDPT**

ALENI / APNON / DUKRA / ESRAS / GERAX / OKSAD / ORNAD / TONKA
 RWY 20 (199°)

When instructed, contact Sikhuphe APP.

DESIGNATOR	ROUTING	ALTITUDES
	Runway 20	
ALENI 128.000	at MNM 3000 LT direct ALENI	
APNON 128.000	at MNM 4000 RT direct APNON	
DUKRA 128.000	at MNM 4000 RT direct DUKRA	
ESRAS 128.000	at MNM 4000 RT direct ESRAS	
GERAX 128.000	at MNM 4000 RT direct GERAX	
OKSAD 128.000	at MNM 4000 RT direct OKSAD	
ORNAD 128.000	at MNM 3000 LT direct ORNAD	
TONKA 128.000	at MNM 3000 LT direct TONKA	

Changes: Country name

06-SEP-2018
SHO-FDSK

Eswatini **Manzini** King Mswati III/Sikhuphe Intl

ARRIVALs


STAR

STAR

King Mswati III/Sikhuphe Intl **Manzini** Eswatini

NIL

ARRIVALs



Changes: Country name

© Lido 2018


06-SEP-2018
SHO-FDSK

Eswatini **Manzini** King Mswati III/Sikhuphe Intl


IAC

7-10

ILS or LOC 20



1	2	3	5	7	9.1	LOC 3.01° D ISK
1410	1730	2050	2680	3320	4000	



20	Cat 1 DME 1)	LOC DME		Circling 2)
C	ft - m/km ft	200 - 550 1290	280 - 750 1360	1080 - 2.4V 2170
D	ft - m/km ft	200 - 550 1290	280 - 750 1360	1080 - 3.6V 2170

1) FD, AP or HGS required, else RVR 750m
2) E of AD only

Changes: Country name


06-SEP-2018
SHO-FDSK

Eswatini **Manzini** King Mswati III/Sikhuphe Intl


IAC

7-20

VOR 02



3.00° D VSK	8.6	6	5	4	3	2	02	3.0° YCZ 900m 60 HL	3580 x 45	420	1092 / 39hPa	TDZ ---%	-0.1%
	4000	3160	2840	2520	2200	1880	HL-S						



02	VOR DME					Circling ¹⁾
C	ft - m/km ft	500 - 1.8 1590				1080 - 2.4V 2170
D	ft - m/km ft	500 - 1.8 1590				1080 - 3.6V 2170

1) E of AD only

Changes: Country name


06-SEP-2018
SHO-FDSK

Eswatini **Manzini** King Mswati III/Sikhuphe Intl

IAC

7-30

VOR 20



20		VOR DME		Circling ¹⁾	
C	ft - m/km ft	450 - 1.4 1530		1080 - 2.4V 2170	
D	ft - m/km ft	450 - 1.4 1530		1080 - 3.6V 2170	

1) E of AD only

Changes: Country name