



The series R resistor should be right after the amplifier, to current limit a GND short on the cable.

The short circuit should be limited to what the INA333 can source, $\sim 10\text{mA}$.

$5\text{V} / 10\text{mA} = 500\text{ ohm}$.

Parry Zhuo & Daniel Mahmoud
BCIT Racing

Sheet: /
File: Amplifier.kicad_sch

Title: Amplifier

Size: A Date: 2025-08-16
KiCad E.D.A. 9.0.3

Rev: 01
Id: 1/1