




7 BCN3D+ ASSEMBLY GUIDE

SPOOL MOUNT




7 BCN3D+ ASSEMBLY GUIDE

SPOOL MOUNT




1




BOM ID	Description	Qty
A1	Spool holder left	1
A2	Spool holder right	1

2




Check that the Spool Spacer is oriented such that the spacer ring is toward the bearing, see Fig.

BOM ID	Description	Qty
B1	DIN934 M8	2
B2	608ZZ Radial bearing	2
B3	Spool spacer	1
B4	Butterfly screw M8x30	2



3



4

x2

