

# Common Settings

## 一、 Sleep time(Default 20s)



Sleep time  
SET(%%ALLTIMSET)



20s(%%ALLTIM00)



5m(%%ALLTIM04)



30s(%%ALLTIM01)



10m(%%ALLTIM05)



60s(%%ALLTIM02)



20m(%%ALLTIM06)



2m(%%ALLTIM03)



No sleep  
(%%ALL\*TIDIS)

## 二、 Shutdown, Restore factory settings, Read version information



Shutdown  
(%%POWEROFF)



Read Version  
(%%Version)



Read Hardware  
(%%HDVersion)



Restore factory  
settings(%%Restore  
)

## 三、 Bluetooth work mode ( Default HID Mode )



HID Mode  
(%%BT\_HID)



SPP Mode %%BT\_SPP)

## 四、 Work Mode ( Default normal mode )



Normal Mode (%%ALLPT-SET)



Take stock Mode SET  
(%%ALLMEM-SET)



Upload data (%%ALLMEM-  
SC)



Keep the data in memory  
(%%ALLAEM-SET)



Total of  
records(%%ALLMEM-ZS)



Clear records(%%ALLMEM-  
QC)

# Advanced settings

## 一、Channel Setting (2.4G(01-20)433M(01-30))



Make a pair (%%EZPair)

## 二、 Buzzer hint 1: “Scanned barcode” Tweet (Default OFF)



ON (%%BZOpen1)



OFF (%%BZClose1)

## 三、 Buzzer hint 2 : “RF Uploaded successfully” Tweet ( Default OFF )



ON(%%BZOpen2)



OFF(%%BZClose2)

## 四、 Display battery power ( Only for Bluetooth Scanner )



Display battery power  
(%%Batt)