



Step 1: Enable Bluetooth on the Mac.




Step 2: Long trigger the Bluetooth Scanner when Mac show the following screen, the "General Bluetooth HID Barcode S" device will appear after long trigger 60 seconds, then click "Pair", the scanner will have a long beep.






Step 3#. System will show the following screen after making pair. Click **"Continue"**



Step 4: Scanner any barcode when the system show the following screen.



The setup is done.

For more: <https://github.com/BEVOLINK/Barcode-Scanner>