

MTE321 Formulas

Stresses

Deformation Elongation

$$\delta = \frac{FL}{EA}$$

$$\delta = \frac{\sigma L}{E}$$

Torsional Forumals

Stress

R is the radial distance

$$\tau = \frac{Tr}{J}$$

$$Z_p = \frac{J}{c}$$

$$\tau_{max} = \frac{T}{Z_p}$$

Deformation

θ is the angle of twist across L

For non-circular shafts K is section polar second moment of area and Q the section polar modulus

$$T = \frac{P}{\omega} \quad T_{lb-in} = 63000 \frac{P}{\omega}$$

$$\theta = \frac{TL}{GJ}$$

$$Non-Circular \tau = \frac{T}{Q}$$

$$Non-Circular \theta = \frac{TL}{GK}$$

Thin-Walled Closed Tubes

A = median area boundary, U is length of median boundary

$$K = \frac{4A^2t}{U}$$

$$Q = 2tA$$

Shear Stress

V section shear force, Q is the first moment area, and t is the section thickness

$$\tau_{(y)} = \frac{VQ}{It}$$

$$Rectangular \ Beam \ \tau_{max} = \frac{3V}{2A}$$

$$Solid \ Round \ Beam \ \tau_{max} = \frac{4V}{3A}$$

$$Hollow \ Round \ Beam \ \tau_{max} = \frac{2V}{A}$$

Beam Bending

M is the moment at the section, y is the distance from the neutral axis

$$\sigma_y = -\frac{My}{I}$$

Stress Concentrations

Stress Concentration Factor

K_t is material and loading dependent, values greater than 3 are a waste

$$\sigma_{max} = K_t \sigma_{nom}$$

Curved Beam Bending

$R = \frac{A}{ASF}$
 r = distance to required stress location
 r_c = centroid distance
 A = cross-sectional area

$$\sigma_{(r)} = \frac{M(\theta)(R-r)}{Ar(r_c-R)}$$

Thermal Strain

$$\epsilon_x^m = -\alpha \delta T$$

Principle Stresses

$$\tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

$$Max \ \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

$$Min \ \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

Lecture 5

Loading

$$\sigma_m = mean \ stress = (\sigma_{max} + \sigma_{min})/2$$

$$\sigma_a = stress \ amplitude = (\sigma_{max} - \sigma_{min})/2$$

$$R = stress \ ratio = \sigma_{min}/\sigma_{max}$$

$$A = stress \ ratio = \sigma_a/\sigma_m$$

$$Loading \ Cycle : period \ between \ peaks$$

Fatigue Testing

Endurance Limit

Goodman Method

Design: Dynamic Loads

Stress

Periodic

Fluctuating $\sigma_m \neq 0$, $R = -1$
 Pulsating $\sigma_m = 0$, $R = 1$

Endurance Limit

s_a = Stress Amplitude Level
 N : number of cycles to failure
 s_n = fatigue limit
 Assume $s_n = 0.5s_u$ if no data

$$s_a = s_n N^b$$

$$s'_n = C_m C_{st} C_R C_S s_n$$

s_n from table appendix 3
 C_m material flaws
 C_R Reliability Factor
 C_s = size factor (5-12, 5-4 circular), (5-13 for other)

Goodman Method

Gears

Pitch Line Speed

$$V_T = \frac{\pi D \cdot n_p}{12}$$