

# MTE321 Formulas

## Stresses

### Deformation Elongation

$$\delta = \frac{FL}{EA}$$

$$\delta = \frac{\sigma L}{E}$$

### Torsional Formulas

#### Stress

R is the radial distance

$$\tau = \frac{Tr}{J}$$

$$Z_p = \frac{J}{c}$$

$$\tau_{max} = \frac{T}{Z_p}$$

$$Hollow: J = \frac{\pi}{2}(C^4 - C_i^4)$$

$$Solid: J = \frac{\pi}{2}C^4$$

### Deformation

$\theta$  is the angle of twist across L  
For non-circular shafts K is section polar second moment of area and Q the section polar modulus

$$T = \frac{P_W}{\omega} \quad T_{lb.in} = 63000 \frac{P_{hp}}{\omega}$$

$$\theta = \frac{TL}{GJ}$$

$$Non-Circular \tau = \frac{T}{Q}$$

$$Non-Circular \theta = \frac{TL}{GK}$$

### Thin-Walled Closed Tubes

A = median area boundary, U is length of median boundary

$$K = \frac{4A^2t}{U}$$

$$Q = 2tA$$

## Shear Stress

V section shear force, Q is the first moment area, and t is the section thickness

$$\tau_{(y)} = \frac{VQ}{It}$$

$$Rectangular Beam \tau_{max} = \frac{3V}{2A}$$

$$Solid Round Beam \tau_{max} = \frac{4V}{3A}$$

$$Hollow Round Beam \tau_{max} = \frac{2V}{A}$$

$$Q = A_p \bar{y}$$

$$\bar{y} = Distance to central axis$$

$$A_p = \frac{1}{12} t \cdot h \text{ rectangle}$$

### Beam Bending

M is the moment at the section, y is the distance from the neutral axis

$$\sigma_y = -\frac{My}{I}$$

$$\sigma_{max} = \frac{M}{S}$$

## Stress Concentrations

### Stress Concentration Factor

K<sub>t</sub> is material and loading dependent, values greater than 3 are a waste

$$\sigma_{max} = K_t \sigma_{nom}$$

### Curved Beam Bending

R =  $\frac{A}{ASF}$   
r = distance to required stress location  
r<sub>c</sub> = centroid distance  
A = cross-sectional area

$$\sigma_{(r)} = \frac{M(\theta)(R-r)}{A r_o(r-R)}$$

### Thermal Strain

$$Fixed between two walls \epsilon_x^m = -\alpha \Delta T$$

$$\epsilon_x^t = \alpha \Delta T$$

## Principle Stresses

$$\tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

$$Max \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

$$Min \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

$$\tau_{max} = \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

## Static Loads

### Effective Stress

$$Tresca: \sigma' = \frac{\sigma_1 - \sigma_3}{2}$$

$$Von Mises: \sigma_e = \frac{1}{\sqrt{2}} \sqrt{(\sigma_1 - \sigma_2)^2 + (\sigma_1 - \sigma_3)^2 + (\sigma_2 - \sigma_3)^2}$$

### Static Loading

$$N = \frac{s_y}{2\tau_{max}}$$

$$N = \frac{s_y}{\sigma_e}$$

If brittle

$$N = \frac{S_{ut}}{K_t \sigma_1}$$

$$N = \frac{S_{uc}}{K_t \sigma_3}$$

$$\sigma_1 > \sigma_2 > \sigma_3$$

## Design Factors

### A<sub>95</sub> Equivalence

$$Equivalent Diameter: D_e = 0.370D$$

$$General: 0.0766D_e^2$$

Design: Dynamic Loads

Loading

$$\sigma_m = \text{mean stress} = \frac{\sigma_{max} + \sigma_{min}}{2}$$
$$\sigma_a = \text{stress amplitude} = \frac{\sigma_{max} - \sigma_{min}}{2}$$
$$R = \text{stress ratio} = \frac{\sigma_{min}}{\sigma_{max}}$$
$$A = \text{stress ratio} = \frac{\sigma_a}{\sigma_m}$$

Loading Cycle: preriod between peaks

Stress

Periodic

Fluctuating  $\sigma_m \neq 0$  , R = -1  
Pulsating  $\sigma_{min} = 0$ , R =1

Endurance Limit

s<sub>a</sub> =Stress Amplitude Level  
N: number of cycles to failure  
s<sub>n</sub> = fatigue limit  
Assume s<sub>n</sub> = 0.5s<sub>u</sub> if no data

$$s_a = s_n N^b$$
$$s_n^i = C_m C_{st} C_R C_S s_n$$

*C<sub>S</sub> only in bending*

- s<sub>n</sub> from table appendix 3  
C<sub>m</sub> material flaws  
C<sub>R</sub> Reliability Factor Assume 0.99 reliability  
C<sub>s</sub> = size factor (5-12,5-4 circular),(5-13 for other)
- 4. Apply a material factor, *C<sub>m</sub>*, from the following list.  
Wrought steel: *C<sub>m</sub>* = 1.00  
Cast steel: *C<sub>m</sub>* = 0.80  
Powdered steel: *C<sub>m</sub>* = 0.76  
Malleable cast iron: *C<sub>m</sub>* = 0.80  
Gray cast iron: *C<sub>m</sub>* = 0.70  
Ductile cast iron: *C<sub>m</sub>* = 0.66
  - 5. Apply a type-of-stress factor: *C<sub>st</sub>* = 1.0 for bending stress; *C<sub>st</sub>* = 0.80 for axial tension.
  - 6. Apply a reliability factor, *C<sub>R</sub>*, from Table 5–3.
  - 7. Apply a size factor, *C<sub>s</sub>*, using Figure 5–12 and Table 5–4 as guides.

Goodman Method

Dynamic Loads Compressive

( $\sigma_m \leq 0$ )

Von Mises:  $N_1 = \frac{s_n^i}{K_t \sigma_a^i}$

Tresca:  $N_1 = \frac{s_n^i}{K_t \sigma_a^i}$

Dynamic Loads Tensile

( $\sigma_m > 0$ )

Von Mises:  $\frac{K_t \sigma_a^i}{s_n^i} + \frac{\sigma_m^i}{s_u} = \frac{1}{N_1}$

Tresca:  $\frac{2K_t}{s_n^i} (\tau_a)_{max} + \frac{4}{3s_u} (\tau_m)_{max} = \frac{1}{N_1}$

Dynamic Yield Test

*for low  $\sigma_a$  high  $\sigma_m$*

Von Mises:  $\frac{K_t \sigma_a^i}{s_y} + \frac{K_t \sigma_m^i}{s_y} = \frac{1}{N_2}$

Tresca:  $\frac{2K_t}{s_{sy}} (\tau_a)_{max} + \frac{2K_t}{S_{sy}} (\tau_m)_{max} = \frac{1}{N_2}$

Effective safety factor is < of N<sub>1</sub> and N<sub>2</sub>

Gears

Table 8-1

Pitch Line Speed

$$V_T = \frac{\pi D \cdot n_p}{12}$$

Gears

Spur Gears

*Center Distance C* = *R<sub>P</sub>* + *R<sub>G</sub>*

*Speed of Gears:*  $\frac{n_p}{n_G} = \frac{N_G}{N_P}$

*Common Speed:* *v<sub>T</sub>* = *R<sub>1</sub>*ω<sub>1</sub> = *R<sub>2</sub>*ω<sub>2</sub>

*Tangental Acceleration:* *a<sub>T</sub>* = *R<sub>1</sub>*α<sub>1</sub> = *R<sub>2</sub>*α<sub>2</sub>

*Velocity Ratio:*  $VR = \frac{R_G}{R_P} \geq 1 = \frac{N_G}{N_P} = \frac{n_p}{n_G} = \frac{\omega_P}{\omega_G}$

*Circular Pitch:*  $p = \frac{\pi D}{N}$

*Contact Ratio:*  $m_f = \frac{\sqrt{R_{oP}^2 - R_{bP}^2} + \sqrt{R_{oG}^2 - R_{bG}^2} - c \sin \phi}{p \cos \phi}$

*P* = *T*ω

*backlash:* = *w* – *t*

*w* → *Tooth Space*, *distance pitch circle travels between teeth*

Helical Gears

*Circular/Transverse Pitch:*  $p = \frac{\pi}{P_d}$

*Normal Circular:*  $p_n = p \cos \psi$

*Axial Pitch:*  $p_x = \frac{pt}{\tan \psi}$

*Pitch Diameter:*  $D_G = \frac{N}{P_d}$

*Normal Pressure Angle:*  $\phi_n = \tan^{-1}(\tan \phi_t \cdot \cos \psi)$

*Diametral Pitch:*  $P_{nd} = \frac{P_d}{\cos \psi}$

*Axial Pitches in Face:*  $\frac{F_w}{P_x}$

*Normal Diametral Pitch:*  $P_{nd} = \frac{P_d}{\cos \psi}$

Gear Train

$$TV_{nom} = \frac{n_{in}}{n_{out}}$$

Racks

*Velocity of Rack:*  $V_R = V_T = R_p \omega_p = \left(\frac{D_p}{2}\right) \omega_p$

*Displacement of Rack:*  $s = \frac{D_p}{2} \theta_p$

Bevel

$$TV = \frac{\omega_{p1}}{\omega_{GN}}$$