

# MTE321 Formulas

## Stresses

### Deformation Elongation

$$\delta = \frac{FL}{EA}$$
$$\delta = \frac{\sigma L}{E}$$

### Torsional Forumals

#### Stress

R is the radial distance

$$\tau = \frac{Tr}{J}$$
$$Z_p = \frac{J}{c}$$
$$\tau_{max} = \frac{T}{Z_p}$$

#### Deformation

$\theta$  is the angle of twist across L

For non-circular shafts K is section polar second moment of area and

Q the section polar modulus

$$T = \frac{P}{\omega} \quad T_{lb-in} = 63000 \frac{P}{\omega}$$
$$\theta = \frac{TL}{GJ}$$
$$Non-Circular \tau = \frac{T}{Q}$$
$$Non-Circular \theta = \frac{TL}{GK}$$

#### Thin-Walled Closed Tubes

A = median area boundary, U is length of median boundary

$$K = \frac{4A^2t}{U}$$
$$Q = 2tA$$

#### Shear Stress

V section shear force, Q is the first moment area, and t is the section thickness

$$\tau_{(y)} = \frac{VQ}{It}$$
$$Rectangular \ Beam \ \tau_{max} = \frac{3V}{2A}$$
$$Solid \ Round \ Beam \ \tau_{max} = \frac{4V}{3A}$$
$$Hollow \ Round \ Beam \ \tau_{max} = \frac{2V}{A}$$

#### Beam Bending

M is the moment at the section, y is the distance from the neutral axis

$$\sigma_y = -\frac{My}{I}$$

#### Stress Concentrations

##### Stress Concentration Factor

K<sub>t</sub> is material and loading dependent, values greater than 3 are a waste

$$\sigma_{max} = K_t \sigma_{nom}$$

#### Curved Beam Bending

$$R = \frac{A}{ASF}$$

r = distance to required stress location

r<sub>c</sub> = centroid distance

A = cross-sectional area

$$\sigma_{(r)} = \frac{M(\theta)(R-r)}{Ar(r_c-R)}$$

#### Thermal Strain

$$\epsilon_x^m = -\alpha \delta T$$

#### Principle Stresses

$$\tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$
$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$Max \ \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$
$$Min \ \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

## Lecture 5

### Loading

$$\sigma_m = mean \ stress = (\sigma_{max} + \sigma_{min})/2$$

$$\sigma_a = stress \ amplitude = (\sigma_{max} - \sigma_{min})/2$$

$$R = stress \ ratio = \sigma_{min}/\sigma_{max}$$

$$A = stress \ ratio = \sigma_a/\sigma_m$$

$$Loading \ Cycle : period \ between \ peaks$$

#### Fatigue Testing

$$\tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$
$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$Max \ \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$
$$Min \ \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

#### Endurance Limit

$$\tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$
$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$Max \ \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$
$$Min \ \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

#### Goodman Method

$$K_t \tan 2\theta_\sigma = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$
$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$
$$Max \ \sigma_{norm} = \frac{1}{2}(\sigma_x + \sigma_y) + \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$
$$Min \ \sigma_{norm} = \frac{1}{2}(\sigma_x - \sigma_y) - \sqrt{\left[\frac{1}{2}\sigma_x - \sigma_y\right]^2 + \tau_{xy}^2}$$

## Gears

### Pitch Line Speed

$$V_T = \frac{\pi D \cdot n_p}{12}$$