





Oriented pieces:

- Photodiode and LED: orient long legs towards the bottom edge of the board
- Button: the two rightmost holes matter, make sure the button isolates them until pressed



