

Home Automation Stack



The stack contains everything to run FHEM on a Docker host. Mosquitto is used as message broker. SIRI functions are realized with the help of a homebridge container. The complete stack runs on x86 as well as arm architectures. It is very easy to clone its complete productive environment and has a simple way to build a test system.

Todo

- deCONZ Image Container Integration
- DBLog Integration

Requirements

- docker
- docker-compose

Installation raspberrypi

Raspian Download

Download the image of your choice: Raspian Download Unzip the image and install it with:

```
1  sudo dd bs=4M if=2019-09-26-raspbian-buster-full.img of=/dev/mmcblk0
   conv=fsync
2  sync
```

Eject the card and insert it again to mount the filesystems boot & rootfs. Touch a blank file ssh to enable

```
1  sudo touch /media/boot/ssh
2  sync
3  umount /media/boot
4  umount /media/rootfs
```

Eject the card and insert into your raspberry. After that power on the rpi and login with the known

```
1  ssh pi@raspberrypi4
```

```
1  pi@raspberrypi:~ $ passwd
2  Changing password for pi.
3  Current password:
4  New password:
5  Retype new password:
6  passwd: password updated successfully
7  pi@raspberrypi:~ $
```

System Update

```
1  sudo apt-get update
2  sudo apt-get dist-upgrade
```

Raspberry Config

1) Expand the root filesystem (A1 / Advanced Options)

2) Update raspi-config

sudo raspi-config sudo reboot

Intall additional packages

```
1  sudo apt-get install wget git apt-transport-https vim telnet zsh zsh-
   autosuggestions zsh-syntax-highlighting
```

Install docker & docker-compose


```
1 #curl -sSL https://get.docker.com | sh
2 #sudo systemctl enable docker
3 #sudo systemctl start docker
4 sudo apt-get install docker docker-compose
5 sudo usermod -aG docker pi
6 sudo reboot
```

git repository export and start all container

```
1 cd
2 git clone https://github.com/stormmurdock/fhemdocker.git
3 cd fhemdocker
4 docker-compose up
```

Container

Tasmota Admin



The screenshot shows the Tasmota Admin web interface. At the top, there is a navigation bar with 'Start', 'Module', and 'Einstellungen'. Below this, a 'Detail Ansicht' button is visible. The main content is a table with columns: Pos., Name, IP, Status, Signal strength, Version, Laufzeit, and Energie. There are five rows of modules listed. Each row has a set of icons on the right for configuration, editing, deleting, and refreshing. At the bottom of the table, there are buttons for 'Detail Ansicht' and 'Befehl'.

Pos.	Name	IP	Status	Signal	Version	Laufzeit	Energie	Actions
1	sonoffpow1	192.168.1.41	On	100%	5.12.0b	2T 21h 54m 6s	5W 0/0kWh 0.074A	⚙️ ✎️ 🗑️ ↺️
2	sonoffpow2	192.168.1.44	On	82%	5.12.0b	2T 21h 54m 16s	57W 0.191/0.245kWh 0.265A	⚙️ ✎️ 🗑️ ↺️
3	sonoffpow4	192.168.1.47	On	100%	5.12.0b	87T 20h 7m 0s	0W 0/0kWh 0A	⚙️ ✎️ 🗑️ ↺️
4	obi1	192.168.1.68	On	38%	5.12.0b	34T 3h 19m 59s	-	⚙️ ✎️ 🗑️ ↺️
5	obi3	192.168.1.77	On	54%	5.12.0b	63T 2h 50m 22s	-	⚙️ ✎️ 🗑️ ↺️

Abbildung 1: "tasmotaadmin"

Tasmota Compiler




Abbildung 2: "tasmotacompiler"

Homebridge




Abbildung 3: "homebridge"

Portainer




Abbildung 4: “portainer”

ctop

Description

ctop is a commandline monitoring tool for linux containers

ctop - 11:34:11 CET 7 containers							
NAME	CID	CPU	MEM	NET RX/TX	IO R/W	PIDS	
• fhemdocke_adminer_1	e44706321c50	0%	4M / 15.57G	7K / 220B	0B / 0B	1	
• fhemdocke_fhem_1	f2b2468390c	5%	77M / 15.57G	18K / 39K	0B / 276K	4	
• fhemdocke_homebridge_1	b914d7962583	0%	128M / 15.57G	0B / 0B	0B / 60K	39	
• fhemdocke_portainer_1	857f7466414	0%	9M / 15.57G	15K / 1K	0B / 148K	18	
• fhemdocke_tasmocompil...	ffdfe452715	0%	41M / 15.57G	7K / 110B	0B / 4K	18	
• fhemdocke_tasmotaadmi...	fc63ff98efe7	0%	12M / 15.57G	8K / 110B	0B / 8K	10	
• fhemdocke_broker_1	c442b745308f	-	-	-	-	-	

Abbildung 5: “ctop”

Installation

ctop is available in AUR, so you can install it using AUR helpers, such as YaY, in Arch Linux and its variants such as Antergos and Manjaro Linux.

Installation Linux

```
1 sudo wget https://github.com/bcicen/ctop/releases/download/v0.7.3/  
   ctop-0.7.3-linux-amd64 -O /usr/local/bin/ctop  
2 sudo chmod +x /usr/local/bin/ctop
```

```
1 sudo wget https://github.com/bcicen/ctop/releases/download/v0.7.3/  
   ctop-0.7.3-linux-arm -O /usr/local/bin/ctop  
2 sudo chmod +x /usr/local/bin/ctop
```