


PCB1010 Joystick / Knob / OLED Board



20 position 1mm pitch FFC cable
(Connect, copper side down, both sides)



PCB1010 (Top View)
This board routes signals from the Axoloti to a 20 pin connector



PCB1010 (Side View)
This PCB typically has a 40 pin 0.1" female connector



Axoloti Core
This PCB typically has a 40 pin 0.1" male header to mate to PCB1010