




# Attach the thumb tensioner pin



Cut a length of thread twice as long as the hand and tie it using a triple knot through the small hole at on end of the thumb tensioner pin. Pull the knot tight using two pairs of small long nose pliers. Cut the excess thread to about an inch long. Thread the long end of the thread through the remaining hole in the back of the palm and down to the end of the thumb tip as you did with the fingers. Don't tie it to the end of the thumb tip yet!

Use another sheet metal screw to attach the pin and tighten till the front of the pin is level with the front of the gripper box.