


Attach ring finger



Before inserting one of the short knuckle pins ensure that its rectangular head will fit in the rectangular ring finger hole in the palm. If necessary file or sand the pin head to fit.

Press the pin into the rectangular hole for the ring finger using the pliers. Once the tip of the pin is in place insert the ring finger (long) into its joint slot then push the pin in fully. You may need to use a nail punch and hammer to complete this step.