

KNOBS


Nothing plugged in to the input: Knob sets parameter from 0-100%.
Analogue signal plugged into jack: Knob attenuates signal

INPUTS

OUTPUTS

DAEMON default app bundle cheat sheet

To cycle through the apps, press the button. After each button press, the inputs will flash a number of times to signify which number app is running. IE 4 flashes = app number 4.
DAEMON will remember your chosen app when you turn off the power. When you switch your rack on again, DAEMON will start up on the same app as when you switched it off.




KNOBS

Nothing plugged in to the input: Knob sets parameter from 0-100%.
 Analogue signal plugged into jack: Knob attenuates signal

INPUTS

OUTPUTS



Mode
 = Gate stays on until other one goes high
 OR Gate turns off when clock goes low

Gate B plays the same sequence as A,
 but backwards