


Set to YES during all test to avoid motor start


Actual Mow Motor power and

Max Power,
At 80% the mow spirale start,
At 100% during 5 Seconds the motor stop for one minute,
Error can occur by motor driver itself if power really too high,
Reset the mower to reinit the error



The max and min speed of the mow motor,
Speed is automaticly adjust between min and max according the high of the grass,
Reduce noise and increase mowing duration

Use to perfectly set the intensity of motor (Visible only in DEV mode)



motor (visible only in DEV mode)

Result of the compute speed coeff.

The actual motor Speed

Auto mow pattern change when mowing to avoid trackon the grass,swap between random and lane

To test the motor