

```
antenas6@antenas6: ~$ rtl_fm -M wbfm -f 103.3M -s 1000k | play -r 32k -t raw -e s -b 16 -c 1 -V1 -
```

Found 1 device(s):

-: (raw)

Encoding: Signed PCM  
Channels: 1 @ 16-bit  
Samplerate: 1000000Hz  
Replaygain: off

Duration: unknown

In: 0.00% 00:00:00.00 [00:00:00.00] Out: 0  
0: Realtek, RTL2838UHIDIR, SN: 00000001

Using device 0: Generic RTL2832U OEM  
Found Rafael Micro R820T tuner  
Tuner gain set to automatic.  
Tuned to 103368000 Hz.

Oversampling input by: 21x.  
Oversampling output by: 1x.  
Buffer size: 8.13ms  
Exact sample rate is: 1008000.009613 Hz  
Sampling at 1008000 S/s.

Output at 48000 Hz.

In: 0.00% 00:00:06.91 [00:00:00.00] Out: 213k [=====|=====] Hd: 2.3 Clip: 0

User cancel, exiting..

In: 0.00% 00:00:07.03 [00:00:00.00] Out: 221k [=====|=====] Hd: 1.3 Clip: 0

Muestreo de la  
señal.

Finalmente se ingresa el comando de  
sintonizacion de la emisora.

Frecuencia de  
sintonización.

Obteniendo como resultado la información  
en datos de la señal recibida o los datos  
que se reciban en dicha frecuencia.

Signal caught, exiting!