

Options
ID: top_block
Generate Options: WX GUI

Variable
ID: samp_rate
Value: 64k

Variable
ID: sps
Value: 4

WX GUI Notebook
ID: notebook_0
Tab Orientation: Top
Labels: scope, const, freq

Este bloque permite anidar ventanas WX GUI en una sola, por ejemplo en este caso se podrán visualizar las ventanas, WX GUI Scope Sink, WX GUI Constellation Sink y WX GUI FFT Sink. A cada una de estas se le asignó un nombre diferente en Labels, y se les llamo desde el parámetro Notebook seguido de su posición ,como se meuestra en la imagen

Properties: WX GUI Notebook

General Advanced Documentation

ID: notebook_0

Tab Orientation: Top

Labels: ['scope', 'const', 'freq']

Grid Position

Notebook

Properties: WX GUI Scope Sink

General Advanced Documentation

ID: wxgui_scopesink2_1

Type: Float

Title: Scope Plot

Sample Rate: samp_rate

V Scale: 0

V Offset: 0

T Scale: 0

AC Couple: Off

XY Mode: Off

Num Inputs: 1

Window Size

Grid Position

Notebook: notebook_0, 0

Trigger Mode: Auto

Y Axis Label: Counts

Aceptar Cancelar Aplicar

Aceptar Cancelar Aplicar