

Eurorack CV Input

IN: -5V to +5V
OUT: 0V to +3.3V (Inverted)

