

# WAGA Flarm Tool & Simulator User Notes

## Introduction

The Flarm Tool and Simulator (the Tool) is intended to be a tool to assist developers of Flarm or SoftRF displays. It was built for testing the SkyView WAGA Display but is likely to be useful for other displays.

The Tool is built using MS Access and VBA coding. This platform was chosen due to the database intensive nature of the simulations and the ease of building a user interface. It is a rough tool, not a 'polished' programme. Some understanding of MS Access VBA is needed to set up custom simulations and change parameters.

Simulations are constructed as Flarm data sentences (\$PFLAU and \$PFLAA) stored as records in Access data tables. The Sim-Tx Form in the Access database creates a time variable trigger that initiates sending data sentences sequential read from the selected simulation data table. The data is sent directly by hard wiring from the PC data port (via a RS232 to TTL converter) to the Skyview Serial input port. Simulations loop continuously.

The SkyView requires GPS fix data (\$GPGGA and \$GPRMC) in order to activate the radar screen. GPS data may be embedded as discrete records in the simulation tables or the Tool can interleave GPS data (both sentence types in one trigger cycle) for a pre-set static location with the Flarm sentences as they are sent.

ID	Data
1	\$GPGGA,120000,4518.8701,N,07550.2500,W,1,12,0.92,1000.0,M,-34.3,M,,*75
2	\$GPRMC,120000,A,4518.8701,N,07550.2500,W,0.0,0.0,100223,,,A*65
3	\$PFLAU,1,1,2,1,0,333,0,-50,2236,C043EC*21
4	\$PFLAA,0,2000,-1000,-50,1,C043EC,0.00,0.00,0.00,0.00,1*32
5	\$GPGGA,120001,4518.8779,N,07550.2363,W,1,12,0.92,1001.0,M,-34.3,M,,*79
6	\$GPRMC,120001,A,4518.8779,N,07550.2363,W,23.1,51.0,100223,,,A*6C
7	\$PFLAU,1,1,2,1,0,282,0,-51,2251,C043EC*2A
8	\$PFLAA,0,2010,-1011,-51,1,C043EC,334.00,-26.00,2256.00,0.50,1*19
9	\$GPGGA,120002,4518.8833,N,07550.2202,W,1,12,0.92,1002.0,M,-34.3,M,,*7E
10	\$GPRMC,120002,A,4518.8833,N,07550.2202,W,23.1,63.0,100223,,,A*69
11	\$PFLAU,1,1,2,1,0,270,0,-52,2265,C043EC*23
12	\$PFLAA,0,2022,-1020,-52,1,C043EC,28.00,54.00,26.00,0.50,1*08
13	\$GPGGA,120003,4518.8867,N,07550.2031,W,1,12,0.92,1003.0,M,-34.3,M,,*7D
14	\$GPRMC,120003,A,4518.8867,N,07550.2031,W,23.1,75.0,100223,,,A*6C
15	\$PFLAU,1,1,2,1,0,258,0,-53,2279,C043EC*25
16	\$PFLAA,0,2035,-1025,-53,1,C043EC,42.00,14.00,26.00,0.50,1*02
17	\$GPGGA,120004,4518.8872,N,07550.1855,W,1,12,0.92,1004.0,M,-34.3,M,,*70
18	\$GPRMC,120004,A,4518.8872,N,07550.1855,W,23.1,87.0,100223,,,A*6B
19	\$PFLAU,1,1,2,1,0,246,0,-54,2292,C043EC*28

*Example Simulation table with GPS data embedded and each sentence ends with a CheckSum (the 2 characters after the \*)*

## **Limitations**

The simulations created with the Tool must be regarded as approximations only. It can be used for demonstrations, but the resulting radar displays may distort time, distance and apparent traffic path and speed. The major limitations are:

- ThisAircraft is effectively stationary, unless real recorded or meticulously created data is used in the tables. This means the apparent traffic paths are not truly realistic other than when headed directly towards or away from ThisAircraft.
- The Tool sends data sentences at regular intervals whereas, in reality, data is received at the SkyView most likely in an irregular stream eg as \$PFLAA data is received from multiple different traffic targets. There may be 3 say \$PFLAA sentences for every \$PFLAU.

## **Checksum**

The SkyView requires that each data sentence has a valid CheckSum else it will ignore the data. An example CheckSum looks like \*68 where the number 68 is the actual CheckSum value. The Tool has a CheckSum calculator which can append the required value if it is missing from the data sentence.

There are numerous online CheckSum calculators eg <https://nmeaChecksum.eqth.net/>

## **Flarm data sentences**

There are two main sentence types used to pass traffic data and alarms which start with the keys \$PFLAU and \$PFLAA.

**\$PFLAU.** This is a once a second heartbeat from the transceiver and the primary conveyor of threat/alarm information. Traffic is located by relative bearing and distance from ThisAircraft. Plus relative vertical height above/below.

**\$PFLAA.** This passes data on other proximate aircraft, including alarm information. Traffic position is given by relative distance 'north' and 'east' but relative to ThisAircraft track, so really it is in front/behind and left/right. Plus relative vertical height above/below. The 'Source' field can determine if the traffic is Flarm, ADSB or Mode-S.

Definitions of the sentence structures and parameters can be found in Flarm documents FTD-012 and FTD-014. All these parameters can be set or modified in the custom simulations. Take care to understand the fields formats and units.

## **PowerFlarm Built in simulations**

PowerFlarms have 6x built-in traffic simulations, each intended to last approx 30 seconds. If a PowerFlarm is connected to the SkyView Display, then the Tool can issue the required \$PFLAF commands to the PowerFlarm that will cause it to commence outputting the selected simulation.

The 6x PowerFlarm simulations have been recorded and are included as Tables in the simulation database. It is thus not necessary to connect the SkyView to a Flarm in order to use the PowerFlarm sims.

Since the records in these tables include a CheckSum, then following any modification to the fields in these records, the CheckSum must be calculated and updated. It would be easier, to strip the CheckSum from the data and then use the tool's CheckSum function to automatically calculate and append the CheckSum as the data is sent.

### **Custom simulations**

The tool can save a large number of custom created simulations. The simulations can be constructed from a single type of Flarm sentence or combining the 2 types.

Examples are included in the database where Single Flarm sentence type simulations can be constructed directly in the MS Access tables by entering data into cells for each field and the programme automatically concatenates all the rows fields into a CSV sentence in the 'Data' field/column (without CheckSum).

Mixed Flarm Sentence types are best created by the following steps:

1. Create an MS Access table for each sentence type
2. Copy/paste the calculated/concatenated field of each table to separate excel sheets. Do not separate out the fields.
3. Add a column alongside the data and insert a numbering scheme that will be used to sort the data when the two files are merged. Eg if alternating \$PFLAU with \$PFLAA records, then give odd numbers to the PFLAU records and even numbers to the \$PFLAA records.
4. Append the \$PFLAA records (with the numbering) to the end of the \$PFLAU data.
5. Sort by the number column.
6. Create a new data table in the MS Access tool and copy the merged data into this table.

Simulations can be constructed as either:

**Sequential lines.** Sentences are entered in every record of the sim table and sent at the rate of 1/SimDelay. Ideally the \$PFLAU sentence should be sent once per second. If the Tool is set (FixNeeded=True) to add GPS data, this will interleave the Flarm sentences every other trigger so make allowance for this. Eg set SimDelay=250 (4 triggers in 1 second);

ID	Time	Sentence
1	0	\$PFLAU, ...
2	250	\$GPGGA, ... and \$GPRMC, ...
3	500	\$PFLAA, ...
4	750	\$GPGGA, ... and \$GPRMC, ...
5	1000	\$PFLAU, ...
6	1200	\$GPGGA, ... and \$GPRMC, ...
cont..		

**Time frames.** This method establishes a number of time slots per second. Eg set SimDelay=100ms so that there are slots for 10 sentences per second. In a sim table enter \$PFLAU sentences every 10<sup>th</sup> record (eg 1 per second). Enter GPS data strings in slots 2 and 3. Enter \$PFLAA strings in any of the free slots and leave the remainder empty.

### Simulation settings

Each simulation must be set up in the SimSetting Table. The SimLetter can be any number, letter or combination. The SimTable field entry must exactly match a simulation Table in the database. More simulations can be added as desired.

ID	SimLetter	SimTable	SimDelay	SimFix	SimCSur	Description
2	A	Sim_PF6_noObstacle	250	<input checked="" type="checkbox"/>	<input type="checkbox"/>	PowerFlarm Sim 6 without zone and obstacle.
3	B	Sim_Moshe	250	<input type="checkbox"/>	<input type="checkbox"/>	Moshe -3 aircraft.
4	C	PFLAU	250	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Basic alarms. Needs fix and Csum
5	D	PFLAA	250	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Needs fix and Csum
6	E	2Therm_B	250	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2 gliders thermalling around
7	F	Moshe_short	1000	<input type="checkbox"/>	<input type="checkbox"/>	
8	G	PFLAA-ModeS	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mode S
9	H		0	<input checked="" type="checkbox"/>	<input type="checkbox"/>	TBC
10	I	Moshe_Original	500	<input type="checkbox"/>	<input type="checkbox"/>	Moshe 2 sim original
11	J	Tug_Sim_PFLAU	1500	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Tug with glider on tow, then threat
12	K		0	<input type="checkbox"/>	<input type="checkbox"/>	TBC
*(New)			0	<input type="checkbox"/>	<input type="checkbox"/>	

The SimDelay (interval) can be modified in the GUI panel and changes saved in this table.

### Built-in GPS data

GPS data sentences (\$GPGGA and \$GPRMC) for a static position are hard-coded in VBA 'module 1'. This data can be edited provided the correct format is maintained. The code automatically adds the correct CheckSum.

```
Public Sub SendFix()
Dim i As Integer
' ThisAircraft fix data is required if not in sim Table file.
' Any changes to the GPS lines requires recalculation of the CheckSum (the *xx at end of the string),
' which is done automatically. Can be checked using calculator at: https://nmeachecksum.eqth.net/
' ThisAircraft_Track variable in $GPRMC sentence sets the course over the ground. Entered in the GUI.

i = 0
FixData = "$GPGGA,120001,3200|,0000,S,11725.0000,E,1,12,0.92,1001.0,M,-34.3,M,,"
FixData = FixData & NMEAChecksum(FixData) & Chr(13) & Chr(10)

For i = 1 To Len(FixData)
Call PUT_COM_PORT(SkyViewPort, Mid(FixData, i, 1))
Next i

' Example "$GPRMC,120001,A,3200.0000,S,11725.0000,E,23.1,51.0,100223,,A*68" & Chr(13) & Chr(10)
i = 0
ThisAircraft_Track = Forms!Simulations!Txt_Track


FixData = "$GPRMC,120001,A,3200.0000,S,11725.0000,E,23.1," & ThisAircraft_Track & ",100223,,A*"
FixData = FixData & NMEAChecksum(FixData) & Chr(13) & Chr(10)
Debug.Print FixData

For i = 1 To Len(FixData)
Call PUT_COM_PORT(SkyViewPort, Mid(FixData, i, 1))
Next i

End Sub
```

In the Custom simulations panel, you can set This>Aircraft track angle (0-360 degrees). If testing with the radar display in track-up mode, the traffic position(s) on the radar will not change as Flarm sentences provided position data relative to ThisAircraft heading.

### **Typical hardware arrangement**



*The hardware I use*

## **Annex A. Extract from Flarm Document FTD-012**

### **8.1 PFLAU – Heartbeat, status, and basic alarms**

#### **Syntax:**

PFLAU,<RX>,<TX>,<GPS>,<Power>,<AlarmLevel>,<RelativeBearing>,<AlarmType>,<RelativeVertical>,<RelativeDistance>[,<ID>]

#### **Description:**

Heartbeat message; output once per second. Consumers should use this message to detect the presence (and absence) of a compatible data stream.

The sentence summarizes the most relevant status information from the last one-second interval: RF status (RX, TX), power state, and the most important current threat, either traffic, an obstacle, or an alert zone. Consumers with limited resources (e.g. with respect to display capabilities or computational resources) can thus use PFLAU to display basic safety information. Other consumers shall also use PFLAA for extended information.

On devices with SSR/ADS-B Module, non-directional targets are output if enabled (PCASPFLAU configuration setting).

For data port version  $\geq 7$ , Alert Zone alarms are available; see the <AlarmLevel> and <AlarmType> fields.

For data port version  $\geq 4$ , traffic advisory notifications (INFO alarms) are available, see the <AlarmType> field.

### **8.2 PFLAA – Data on other proximate aircraft**

#### **Syntax:**

PFLAA,<AlarmLevel>,<RelativeNorth>,<RelativeEast>,<RelativeVertical>,<IDType>,<ID>,<Track>,<TurnRate>,<GroundSpeed>,<ClimbRate>,<AcftType>[,<NoTrack>[,<Source>,<RSSI>]]

#### **Description:**

Data on other proximate aircraft, intended for connected devices with sufficient CPU performance. This sentence should be treated with utmost flexibility and tolerance on a best effort base. Individual parameters may be empty. The sentence is only sent when port baud rate is 19.2k or higher. In case of serial port congestion or high CPU load, this sentence may be omitted for several objects independent of the alarm level. On devices with SSR/ADS-B Module, ADS-B and non-directional targets are output as well (transponder Mode-C/S only from protocol version 6 and higher).

Obstacle information is not delivered with this sentence.

Note that in case of many targets within range, individual targets, including the most dangerous one, might not be delivered every second, not regularly, or not at all, due to less strict priority handling for the PFLAA sentence. **Always use PFLAU as primary alarm source.** Usually, but not always, the last PFLAA sentence is the one causing the PFLAU content. The other PFLAA sentences are not ordered. Do not expect to receive PFLAU <Rx> times PFLAA sentences, because the number of aircraft being processed might be higher or lower. PFLAA sentences can be based on extrapolated historical data. PFLAA sentences are limited to other aircraft with a horizontal and vertical distance less than the configured range. On Classic FLARM-based devices, the vertical distance is always 500 m. Non-moving aircraft are suppressed.



## Annex B. \$PFLAA and \$PFLAU example simulation tables

Note that the data column is the concatenation of the other columns with commas inserted between fields and no CheckSum. Only the 'Data' column is sent as a sentence. The CheckSum is added by the Tool provided CheckSum=True is set.

ID	\$PFLAA	AlarmLev	Rel_N	Rel_E	Rel_V	IDT	TargetID	Track	GS	ClimbRate	ActTyp	NoTr	Source	Data
1	\$PFLAA	0	0	3500	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,0,0,3500,373,1,DD506F,270,,150,0,2,0,0,
2	\$PFLAA	0	0	3250	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,0,0,3250,373,1,DD506F,270,,150,0,2,0,0,
3	\$PFLAA	0	0	3000	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,0,0,3000,373,1,DD506F,270,,150,0,2,0,0,
4	\$PFLAA	0	0	2750	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,0,0,2750,373,1,DD506F,270,,150,0,2,0,0,
5	\$PFLAA	1	0	2500	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,1,0,2500,373,1,DD506F,270,,150,0,2,0,0,
6	\$PFLAA	1	0	2250	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,1,0,2250,373,1,DD506F,270,,150,0,2,0,0,
7	\$PFLAA	1	0	2000	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,1,0,2000,373,1,DD506F,270,,150,0,2,0,0,
8	\$PFLAA	2	0	1750	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,2,0,1750,373,1,DD506F,270,,150,0,2,0,0,
9	\$PFLAA	2	0	1500	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,2,0,1500,373,1,DD506F,270,,150,0,2,0,0,
10	\$PFLAA	2	0	1250	373	1	DD506F	270	150	0	2	0	0	\$PFLAA,2,0,1250,373,1,DD506F,270,,150,0,2,0,0,
11	\$PFLAA	3	0	1000	0	1	DD506F	270	150	0	2	0	0	\$PFLAA,3,0,1000,0,1,DD506F,270,,150,0,2,0,0,
12	\$PFLAA	3	0	750	-373	1	DD506F	270	150	0	2	0	0	\$PFLAA,3,0,750,-373,1,DD506F,270,,150,0,2,0,0,
13	\$PFLAA	3	0	500	-373	1	DD506F	270	150	0	2	0	0	\$PFLAA,3,0,500,-373,1,DD506F,270,,150,0,2,0,0,
14	\$PFLAA	3	0	250	-373	1	DD506F	270	150	0	2	0	0	\$PFLAA,3,0,250,-373,1,DD506F,270,,150,0,2,0,0,
15	\$PFLAA	1	0	0	-373	1	DD506F	270	150	0	2	0	0	\$PFLAA,1,0,0,-373,1,DD506F,270,,150,0,2,0,0,
16	\$PFLAA	1	0	-250	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,1,0,-250,-373,1,DD506F,235,,150,0,2,0,0,
17	\$PFLAA	1	-250	-500	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,1,-250,-500,-373,1,DD506F,235,,150,0,2,0,0,
18	\$PFLAA	3	-500	-750	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,3,-500,-750,-373,1,DD506F,235,,150,0,2,0,0,
19	\$PFLAA	3	-750	-1000	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,3,-750,-1000,-373,1,DD506F,235,,150,0,2,0,0,
20	\$PFLAA	3	-1000	-1250	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,3,-1000,-1250,-373,1,DD506F,235,,150,0,2,0,0,
21	\$PFLAA	0	-1250	-1500	-373	1	DD506F	235	150	0	2	0	0	\$PFLAA,0,-1250,-1500,-373,1,DD506F,235,,150,0,2,0,0,

ID	\$PFLAU	RX	TX	gPS	Pow	AlarmLevel	Rel_B	AlarmTyp	Rel_V	Rel_D	TargetID	Data
1	\$PFLAU	2	1	0	0	0	90		0	4500	DF0957	\$PFLAU,2,1,0,0,0,90,,0,4500,DF0957
2	\$PFLAU	2	1	0	0	0	90		0	4000	DF0957	\$PFLAU,2,1,0,0,0,90,,0,4000,DF0957
3	\$PFLAU	2	1	0	0	0	90		0	3500	DF0957	\$PFLAU,2,1,0,0,0,90,,0,3500,DF0957
4	\$PFLAU	2	1	0	0	0	90		0	3000	DF0957	\$PFLAU,2,1,0,0,0,90,,0,3000,DF0957
5	\$PFLAU	2	1	0	0	0	90		0	2500	DF0957	\$PFLAU,2,1,0,0,0,90,,0,2500,DF0957
6	\$PFLAU	2	1	0	0	0	90		0	2000	DF0957	\$PFLAU,2,1,0,0,0,90,,0,2000,DF0957
7	\$PFLAU	2	1	0	0	0	90		0	1750	DF0957	\$PFLAU,2,1,0,0,0,90,,0,1750,DF0957
8	\$PFLAU	2	1	0	0	1	90		0	1500	DF0957	\$PFLAU,2,1,0,0,1,90,,0,1500,DF0957
9	\$PFLAU	2	1	0	0	1	90		0	1250	DF0957	\$PFLAU,2,1,0,0,1,90,,0,1250,DF0957
10	\$PFLAU	2	1	0	0	2	90		0	1000	DF0957	\$PFLAU,2,1,0,0,2,90,,0,1000,DF0957
11	\$PFLAU	2	1	0	0	2	90		0	750	DF0957	\$PFLAU,2,1,0,0,2,90,,0,750,DF0957
12	\$PFLAU	2	1	0	0	3	90		0	500	DF0957	\$PFLAU,2,1,0,0,3,90,,0,500,DF0957
13	\$PFLAU	2	1	0	0	3	90		0	250	DF0957	\$PFLAU,2,1,0,0,3,90,,0,250,DF0957
14	\$PFLAU	2	1	0	0	3	90		0	0	DF0957	\$PFLAU,2,1,0,0,3,90,,0,0,DF0957
15	\$PFLAU	2	1	0	0	0	270		0	250	DF0957	\$PFLAU,2,1,0,0,0,270,,0,250,DF0957
16	\$PFLAU	2	1	0	0	0	270		-100	500	DF0957	\$PFLAU,2,1,0,0,0,270,,,-100,500,DF0957
17	\$PFLAU	2	1	0	0	0	270		-100	1000	DF0957	\$PFLAU,2,1,0,0,0,270,,,-100,1000,DF0957
18	\$PFLAU	2	1	0	0	0	270		-85	1500	DF0957	\$PFLAU,2,1,0,0,0,270,,,-85,1500,DF0957
19	\$PFLAU	2	1	0	0	0	270		-65	2000	DF0957	\$PFLAU,2,1,0,0,0,270,,,-65,2000,DF0957
20	\$PFLAU	2	1	0	0	0	270		-45	4500	DF0957	\$PFLAU,2,1,0,0,0,270,,,-45,4500,DF0957
21	\$PFLAU	2	1	0	0	0	270		-30	5000	DF0957	\$PFLAU,2,1,0,0,0,270,,,-30,5000,DF0957
22	\$PFLAU	2	1	0	0	0	270		0	5500	DF0957	\$PFLAU,2,1,0,0,0,270,,0,5500,DF0957
23	\$PFLAU	2	1	0	0	0	270		45	6000	DF0957	\$PFLAU,2,1,0,0,0,270,,45,6000,DF0957
24	\$PFLAU	2	1	0	0	0	270		80	6500	DF0957	\$PFLAU,2,1,0,0,0,270,,80,6500,DF0957
25	\$PFLAU	2	1	0	0	0	270		120	7000	DF0957	\$PFLAU,2,1,0,0,0,270,,120,7000,DF0957
26	\$PFLAU	2	1	0	0	0	270		160	7500	DF0957	\$PFLAU,2,1,0,0,0,270,,160,7500,DF0957