

# *Lumbar Support and Headrest Pillows Installation and Care*



Assembly instruction manuals available at:

V2.1 013023B

<http://bit.ly/ow-manuals>

by **SimFab**.com

If your item is damaged, defective or missing parts, please contact us first directly at Email: [info@SimFab.com](mailto:info@SimFab.com) or Toll Free: **1-888-299-2746**

As the manufacturer, our knowledge of your new product ensures that we will be able to assist you promptly and accurately.


For invoices and other price information, please refer to your market place account for more details. Alternatively, you can always email us at [info@SimFab.com](mailto:info@SimFab.com)

*Available in six matching colors: racing seat,  
lumbar and headrest pillows*



## Lumbar Pillow Installation

1. Slide male buckles between seat base and backrest





2. Slide female buckles through seat backrest openings



3. Connect female and male buckles. Ensure elastic straps are not twisted



## Headrest pillow installation

Install headrest pillow strap through backrest openings through the following steps.



1. Pull elastic strap equally through each of the seat backrest openings and hold each loop with plastic buckle as shown.





2.



3.



4.



5.



## Headrest pillow options

Option A, headrest pillow strap through backrest openings.





Option B, headrest pillow strap over top of seat backrest.



## Care

Remove foam from pillow cover and wash cover by hand.  
Wash material gently with light detergent and cold water.  
Do not wash pillow covers in washing machine.





## Specifications:

Recliner: max: 170 degrees

Construction: tubular steel frame with elastic strap supports

Seat Materials: high-density cold cure foam filling; Fabric, Steel chassis

## Instructions during use and care:

Move simulator around with caution to avoid collision.

Keep out of direct sunlight and outdoor use.

Watch fingers when adjusting recliner.

Placing heavy or sharp objects on the seat may damage the surface material.

Do not use abrasive or chemically aggressive materials on the seat.

Use dry cloth or soft brush to clean the chair.

## Dimensions:



## Warranty Information

### Return Policy

### Terms And Conditions

<http://homeracer.com/ow-termsandconditions.html>

