

SWDIO Interface

Interface LEDs

Serial & Programming Interface

Temp Up and Down Buttons

3V3 Power Supply

Reset & Boot

NTC Thermistors

Hotplate Driver

Title: USB Hotplate

Rev: 1.0