




① Dilution of IAV amplicons




② Addition of Rapid Barcodes (SQK-RBK110.96)




③ Rapid Barcode Incubation




⑦ Wash Flow Cell, Recover Pores (up to 10X reuses)



⑥ Flow Cell Priming, Loading and Sequencing



⑤ Rapid Adapter Incubation



④ Sample Pooling and Magnetic Bead Clean-up

