



create\_tool(t11, "microwave")