

REAR VIEW ROTATED 180° WITHOUT FAN TRAY

ADD GASKET FAR SIDE (EC201473). PLACE GASKET OVER CONNECTORS ON PCB. THEN PLACE REAR PANEL. OVER PCB CONNECTORS. THIS WILL ALIGN GASKET WITH METAL.

CLAMP ON FERRITE (EC201468 QTY 2)
CLAMP FOR FERRITE (EC201469 QTY 2)
COVER FERRITE ASSEMBLY WITH HEATSHRINK (CE1V0026)

CLAMP ON FERRITE (EC201468 QTY 2)
CLAMP FOR FERRITE (EC201469 QTY 2)
COVER FERRITE ASSEMBLY WITH HEATSHRINK (CE1V0026)

FERRITE CORE (EC200280)
ADD 2 TURNS OF WIRE FROM A4-PS EXCEPT GND TO FERRITE.
ZIP TIE FERRITE ASSEMBLY TO CABLE TIE MOUNT (EC200466)
TIE MOUNT TO POWER SUPPLY ALL COVER ASSEMBLY WITH HEATSHRINK

FERRITE CORE (EC200280)
ADD 2 TURNS OF WIRE FROM A5-PS EXCEPT GND TO FERRITE.
ZIP TIE FERRITE ASSEMBLY TO CABLE TIE MOUNT (EC200466)
84-40 X 1/4 PAN HB SCR TO VOLTAGE SELECT PCB.
MOUNT TIE MOUNT ON TOP OF PCB.

STRIP (OF 3/4" X 17" CONDUCTIVE TAPE (CE1M0244))
CENTER TAPE BETWEEN RAIL AND REAR COVER (TOP AND BOTTOM)
DO NOT OVER LAP ONTO SIDES

EDGE OF REAR COVER

EDGE OF REAR RAIL

WHEN AMP COVER PRESENT
USE FOAM GASKET (EC201483)
JUSTIFY TOWARD REAR OF UNIT
INSIDE THE GROOVE OF THE RAIL
(TOP AND BOTTOM)

WHEN AMP COVER PRESENT
USE FOAM GASKET (EC201483)
JUSTIFY TOWARD FRONT OF UNIT
INSIDE THE GROOVE OF THE RAIL
GASKET TO RUN ENTIRE LENGTH OF RAIL.

TOP VIEW WITH TOP COVERS REMOVED

TOP VIEW WITH AMP COVERS REMOVED

**LEFT SIDE VIEW WITH LEFT SIDE PANEL,
POWER SUPPLYS AND PCBS REMOVED**

TOP VIEW WITH TOP COVERS REMOVED

TOP VIEW WITH AMP COVERS REMOVED