





or-ing allows both the swd header and usb to be used at the same time, since neither will back feed into eachother. although a jumper has been added since some swd programmers use this voltage rail as a sense pin

Rev:
Id: 2/2