


1:1



Opening at back for wires
that go to the tracks and points.

Connector on left
side for connection
to the handheld
speed controller.

1:1

