



ResInsight User Course

2021 Q3

1. Welcome, course layout and introductory remarks
2. ResInsight Introduction and Overview
3. Hands-on Exercises
 - a) 3D Grid Visualization
 - b) 3D Grid Inspection Features – Intersections
 - d) 2D Contour Map
 - e) Flow Diagnostics
 - f) Summary Plots
 - g) Summary Plots – calculated curves
 - h) Observed Data Plots
 - i) Ensemble Plots (1 of 2)
 - j) Ensemble Plots (2 of 2)
 - k) Plot Templates
 - l) RFT Plots
 - m) Ensemble RFT Plots
 - n) Correlation Analysis
 - o) Analysis Plot



2021.04

Support and Resources

Main help page

<https://resinsight.org/>

Tutorials and recordings

Tutorial site for ResInsight

<https://github.com/CeetronSolutions/resinsight-tutorials>

Video recording of selected tutorials

https://www.youtube.com/channel/UCEJoH_ti1YZXz4hPMMeAKMgw

Overview of the interface for 3D visualization

<https://github.com/CeetronSolutions/resinsight-tutorials/blob/main/tutorials/graphical-user-interface/graphical-user-interface.md>




2021.04

Preparations

Test models used in tutorials are available from <https://github.com/CeetronSolutions/resinsight-tutorials>

Either clone the GitHub repository, or select “**Download ZIP**” from the **Code** menu




Conventions

In this document, **bold text** indicates an object in the property tree. Menu item text is “written in quotes”.

Example

Select “New Intersection” from **Intersections**.




Tips and tricks

Please close the existing project (“File->Close Project”) before starting a new tutorial. This will help you to avoid confusion caused by data from previous tutorials.

a) 3D Grid Visualization

Objective: Get familiar with basic visualization concepts

1. Import grid data using “Import Eclipse Case” from folder “norne”
2. In Project Tree, select **Cell Result**
3. In Property Editor, change “Result Property” to “PRESSURE”
4. Move to the last time step using the play toolbar button
5. Click on different cells, and investigate the plots for Relative Permeability Plot, PVT Plot and Result Plot
6. To see the simulation wells, turn off **Grids** (see snapshot hint to the right)
7. Select **Simulation Wells** in the Property Editor
8. Enable **Disks** in the **Visibility** group. Data source for the disks can be changed in the **Disks** group at the bottom of the **Property Editor** for Simulation Wells
9. Enable **Well Connection Factors**. Click on the well connection factors star geometry and investigate the values in the **Result Info** panel.




You can change how mouse interaction changes the view in “Edit->Preferences->Navigation Mode”. See also

<https://resinsight.org/getting-started/modelnavigation/>

Online tutorial


<https://github.com/CeetronSolutions/resinsight-tutorials/blob/main/tutorials/grid-visualization/grid-visualization.md>



b) 3D Grid Inspection Features – Intersections

Objective: Able to show and manage intersections

1. Import grid data using “Import Eclipse Case” from folder “norne”
2. Turn off grid visualization to see faults
3. Right-click on the surface of the grid model, and select “Intersections->Polyline Intersection”
4. Select a few points on the surface to define an intersection, and click “Stop picking points” in the Property editor
5. Turn off **Grids** and **Faults** in the **Project Tree**




6. Mark the checkbox in front of the intersection object in the folder “2D Intersection Views”
A flat 2D intersection view is displayed
7. Right-click on a simulation well and select **New Intersection**. Activate the corresponding 2D intersection view

<https://resinsight.org/3d-main-window/derivedresults/>

c) 3D Grid Inspection Features – Fault Analysis

Objective: Able to show and manage cell edge results, formations, Allan diagrams

1. Import grid data using “Import Eclipse Case” from folder “norne”
2. Move to the last time step using the play toolbar button
3. In the Property editor open folder **Faults**. Right-click fault “GH”, and select “On – Others off”
4. Activate **Separate Fault Result**, and select this object
5. In the **Property Editor**, select Type “Static”, and select result “TRANXYZ”. Now you can see transmissibility for all **NNCs** across the fault.
6. Create a new view
7. Import formations using “File->Import->Import Formation Names”, select file “norne/Norne_Fm.lyr”
8. Turn off grid visualization to see faults
9. In the Property editor open folder **Faults**. Right-click fault “GH”, and select “On – Others off”
10. Activate **Separate Fault Result**, and select this object
11. In the **Property Editor**, select Type “Allan Diagrams”, and select result “Formation Allan”.
12. Click on the fault, and investigate the text output in the **Result Info** dialog
13. Make sure there are at least two views in your project
14. Right-click in the 3D scene (outside the grid model), and select “Compare To: -> Name of other view”
15. Manipulate the slider to see data from the two results
16. Create a new view
17. Turn on **Cell Edge Result**. By default, the MULT values are mapped onto the edges of the cells. Click on cells defining close to a fault, and investigate the text output in the **Result Info** dialog




<https://resinsight.org/3d-main-window/3dviews/>
<https://resinsight.org/3d-main-window/allandiagrams/>

d) 2D Contour Map


Objective: Create and configure a 2D contour map

1. Open the main 3D plot window
2. Import grid data using “Import Eclipse Case” from “norne”
3. Contour Map of SWAT
 - a. In the right click menu of the view, select “New Contour Map from 3d view”
 - b. Optional: Minimize the view “**View 1**” to avoid confusion
 - c. In the generated contour map, turn off visualization of faults
 - d. Select **SWAT**



<https://resinsight.org/3d-main-window/contourmaps/>

4. Contour Map of Oil Column
 - a. From the right click menu of the **Contour Map**, select “Duplicate Contour Map”
 - b. Optional: Minimize the original contour map to avoid confusion
 - c. Select object **Map Projection**
 - d. Select “Oil Column” from **Result Aggregation**
 - e. Compute oil column for a selection of formations
 - i. Import formations (see previous tutorial)
 - ii. Create property filter based on “Formation Names”
 - iii. In property filter, select formations “Garn 2” and “Garn 3”
5. In the “Windows” menu, select “Tile Windows” to see both plots next to each other




e) Flow Diagnostics

Objective: Get an overview of how Flow Diagnostics data is accessed and visualized

1. Import grid data using “Import Eclipse Case” from folder “norne”
2. Select **Cell Result**, and change type to “Flow Diagnostics”
3. Select single injector **C-2H**
 - a. Select “Forward Time of Flight” (unit for time is years)
 - b. Select water, and go to second time step
 - c. Create a property filter, show cells close to the injector by reducing the max value
4. Create new view, select producer **B-2H** and “Reverse Time of Flight”
 - a. Create property filter
 - b. Select “Well Plots->Plot Well Allocation” in right click menu of **B-2H**
 - c. Select “Show Contributing Wells” for **B-2H** in right click menu of **B-2H**
 - d. Enable “Communication Lines” on “Simulation wells”

<https://resinsight.org/plot-window/flowdiagnosticsplots/>



f) Summary Plots


Objective: Able to configure summary plots with curves

Open main application plot window and select “Import Summary Case” from “norne”

1. Open main application plot window and select “Import Summary Case” from “norne”
2. From right click menu of the default generated plot, select “Edit Summary Plot”
3. Remove the default curve
4. Add curves for WOPT for B-3H and B-4H, and close the dialog by clicking OK button

Online tutorial

<https://github.com/CeetronSolutions/resinsight-tutorials/blob/main/tutorials/summary-plot/summary-plot.md>



g) Summary Plots – calculated curves

Objective: Able to configure summary plots with curves and calculate a derived curve



1. Open main application plot window and select “Import Summary Case” from “norne”
2. From right click menu of the default generated plot, select “Edit Summary Plot”
3. Remove the default curve
4. Add curves for WOPT for B-3H and B-4H, and close the dialog by clicking **OK** button
5. Open the curve calculator by clicking a button in the toolbar



6. Calculate the sum of WOPT for B-3H and B-4H, select “Calculate” then close the curve calculator
7. Open the plot editor
8. Add the calculated curve by selecting the “Calculated” summary type, and close the dialog by clicking **OK** button

Online tutorial


<https://github.com/CeetronSolutions/resinsight-tutorials/blob/main/tutorials/summary-plot/summary-plot.md>



h) Observed Data Plots

Objective: Import and visualize curves from both simulated and observed data


1. Open a text editor and look at the content of "norne_well_data" to see what data we are supposed to import
2. Open plot window and select "Import Summary Case" from "norne"
3. Import observed data files in folder "norne_well_data/BHP_B1-H.csv" from menu "Import->Import Observed Data"
4. Enable the checkbox "Use Custom Date Time Formant" and type the string **yyyy-MM** in "Custom Date Time Format".
5. Create a new plot with observed and simulated data for **WBHP** for well **B-1H**
6. Import all observed data files in folder "norne_well_data/BHP_B1-H_error.csv" from menu "Import->Import Observed Data"
7. Enable the checkbox "Use Custom Date Time Formant" and type the string yyyy-MM in "Custom Date Time Format".
8. Create a new plot with observed and simulated data for **WBHP** for well **B-1H**, make sure you show curve data including error data



i) Ensemble Plots (1 of 2)

Objective: Import of ensemble data and plot ensemble curves

1. Import base ensemble
 - a. Import data using “Import Ensemble” and Path pattern to
“reek_ensemble\3_r001_reek_50\realization-0\base_pred\eclipse*”
The text “realization-N” is replaced with “realization-*” automatically in the Effective filter
 - b. Click **Find** and **OK**
2. Create a new plot of well oil production total for well **OP_5**
3. In the property editor for the generated ensemble curve set, change “Coloring Mode” to “By Ensemble Parameter”
4. Test with different settings for Statistics curves in the property editor and see the effect in the plot



j) Ensemble Plots (2 of 2)

Objective: Compute and show difference between two ensembles

1. Import base ensemble (can be skipped if data was loaded in previous tutorial)
 - a. Import data using "Import Ensemble" and set the root folder to "reek_ensemble\3_r001_reek_50\realization-0\base_pred\eclipse*"
 - b. Click **Find** and **OK**
2. Import prediction ensemble
 - a. Import data using "Import Ensemble" and set the root folder to "reek_ensemble\3_r001_reek_50\realization-0\pred_op6\eclipse*"
 - b. Click **Find** and **OK**
3. Create delta ensemble
 - a. In right click menu of **Summary Cases**, select "New Delta Ensemble"
 - b. Select "pred_op6" as **Ensemble 1**
 - c. Select "base_pred" as **Ensemble 2**
 - d. Create a new plot, select ensemble "Delta(pred_op6, pred_op6)", and plot **FOPT**
 - e. In the "Statistics" group, check item "Hide Ensemble curves"
 - f. In the right click menu in the plot, select "Show Plot Data" to see curve values including P10 and P90

k) Plot Templates

Objective: Store plot setup with customized curve appearance for reuse on different data

1. Import multiple summary cases as standalone cases
 - a. Import data using “File->Import->Import Summary Cases Recursively” and set Path pattern to “reek_ensemble\3_r001_reek_50\realization-0\base_pred\eclipse*”
 - b. Click **Find** and **OK**
2. Select two summary cases in the project tree and from the right-click menu select “Open Summary Plot Editor”
The selection from the project tree is applied to the source case selection
3. Select well **OP_1** and select summary vector WOPR (Well oil production rate)
4. Change the curve appearance of the two curves the way you like best
5. In the plot area, activate the right-click menu and select “Save As Plot Template”. Create a folder in your user area and store this plot template in this folder using the template name “wopr_two_cases”
6. Apply an existing template
 - a. In the project tree, select two other summary cases than the ones used to produce template
 - b. From the right-click menu, select “Create Plot from Template”
 - c. Select the plot template you created earlier
7. Make sure the visual settings you stored in the template are applied to the generated plot


Hint: An existing template can be applied to a selection of summary ensemble cases

<https://resinsight.org/plot-window/summaryplottemplate/>

I) RFT Plots

1. Import grid data using “Import Eclipse Case” from folder “norne”
2. Untick simulation well hide simulation wells, easier to see the well path to be imported
3. From right click menu of **Wells**, select “Import Well Paths from File” and select well path “C-1H.dev” in folder “norne_rft”
4. From right click menu of well path **C-1H**, select “Import Well Logs from File”, select “C-1H_RFT_dummy.las”
5. From right click menu of well path **C-1H**, select “Well Plots->New RFT plot”
6. Manipulate the property panel to see how the different curves are changing
7. *Optional: Import formations and see the formation names in the plot*




<https://resinsight.org/plot-window/rftplot/>



m) Ensemble RFT Plots

1. Import data using "Import Ensemble" from folder "model-data/reek_ensemble/1_r001_reek_20_rft"
2. Import observations using "Import Observed FMU Data" from folder "model-data/reek_rft"
3. Select Imported FMU RFT Data 1, and look at the information in the property editor
4. From the right-click menu of **RFT Plots**, select "New RFT Plot"
5. Change the Well to OP_4

<https://resinsight.org/plot-window/ensemblerrftplot/>



n) Correlation Analysis

Objective: Create and configure a Correlation Plot

- Import a Summary Ensemble, and use import path "2020_intro/model-data/reek_ensemble/3_r001_reek_50/realization-*/iter-1"
- From the right-click of a curve, select "Create Correlation Plot from Curve Point ->New Report Plot"
- Click on individual cells in the **Correlation Matrix**, and see how the cross plot is updated
Currently selected cell is indicated by a border in green
- Show Pearson calculation
- Change data source to **WOPT** for all wells **OP_1** to **OP_5**
- Click on individual cells in the **Correlation Matrix**, and see how the cross plot is updated

<https://resinsight.org/plot-window/correlationplots/>

Definition of how the Pearson correlation coefficient is computed


https://en.wikipedia.org/wiki/Pearson_correlation_coefficient#For_a_sample

X is input parameter value, Y is simulated value


$$r_{xy} = \frac{\sum_{i=1}^n (x_i - \bar{x})(y_i - \bar{y})}{\sqrt{\sum_{i=1}^n (x_i - \bar{x})^2} \sqrt{\sum_{i=1}^n (y_i - \bar{y})^2}} \quad (\text{Eq.3})$$

Correlation Report for base_pred at 2004-01-29 00:00


Correlation Matrix for Parameters vs Result Vectors at 2004-01-29 00:00



Correlations for base_pred, FOPT at 2004-01-29 00:00



Cross Plot base_pred, LETSGOF:L_1OG x FOPT at 2004-01-29 00:00



o) Analysis Plot

Objective: Create and configure an Analysis Plot

- Import a Summary Ensemble, and use import path "2020_intro/model-data/reek_ensemble/3_r001_reek_50/realization-0/base_pred"
- Import a Summary Ensemble, and use import path "2020_intro/model-data/reek_ensemble/3_r001_reek_50/realization-0/pred_op6"
- Select **New Delta Ensemble** from right-click on **Summary Cases**
Create a **Delta Ensemble** as the difference between the two cases (pred_op6 - base_pred)
- Select new **Analysis Plot**
- In Property Editor, in group Selected Vectors, click on the button with three dots "..."
 - o Set source **Delta ensemble**
 - o Select wells **OP_1-5**
 - o Select Summary Vector **WOPT**
- Bar Orientation: **Horizontal**
- Select major grouping **Summary Item**
- Select sort by abs(Value)
- Optionally
 - o Show legend
 - o Bar labels

<https://resinsight.org/plot-window/analysisplots/>

