


Yellow  
Arrows are  
the edge  
holes that  
must be  
soldered



Thank you for your purchase, here are some notes on the install

\*The red oval is a solder blob to short D0 to ground (or solder the D0 wire to the LEFT pad)

\*solder all the LPC pins shown

- 1) Install the pin header and LPC board at the same time by taping the pin header to the front of the board, this will make the install much easier
- 2) Make sure to align the edge holes before soldering anything in place

Email me [kekule@chimericsystems.com](mailto:kekule@chimericsystems.com) if you have more questions