



BeagleBone DVI-D Cape Rev A System Reference Manual

Revision 0.2
January 25, 2012



THIS DOCUMENT

This work is licensed under the Creative Commons Attribution-Share Alike 3.0 Unported License. To view a copy of this license, visit <http://creativecommons.org/licenses/by-sa/3.0/> or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA.

All derivative works are to be attributed to BeagleBoardtoys.com.

For more information, see <http://creativecommons.org/licenses/by-sa/3.0/>

For any questions, concerns, or issues submit them to support@beagleboardtoys.com

BEAGLEBONE DVI-D CAPE DESIGN

These design materials referred to in this document are ***NOT SUPPORTED*** and **DO NOT** constitute a reference design. Only “community” support is allowed via resources at Beagleboardtoys.com/support

THERE IS NO WARRANTY FOR THE DESIGN MATERIALS, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE DESIGN MATERIALS “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND

FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE DESIGN MATERIALS IS WITH YOU. SHOULD THE DESIGN MATERIALS PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

We mean it; these design materials may be totally unsuitable for any purposes.

BeagleBoardToys provides the enclosed product(s) under the following conditions:

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by BeagleBoardtoys.com to be a finished end-product fit for general consumer use. Persons handling the product(s) must have electronics training and observe good engineering practice standards. As such, the goods being provided are not intended to be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety and environmental measures typically found in end products that incorporate such semiconductor components or circuit boards. This evaluation board/kit does not fall within the scope of the European Union directives regarding electromagnetic compatibility, restricted substances (RoHS), recycling (WEEE), FCC, CE or UL, and therefore may not meet the technical requirements of these directives or other related directives.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within **30 days** from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies BeagleBoardtoys.com from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

BeagleBoardtoys.com currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**. BeagleBoardtoys.com assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein**.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on BeagleBoardtoys.com environmental and/or safety programs, please contact visit BeagleBoardtoys.com.

No license is granted under any patent right or other intellectual property right of BeagleBoard.org covering or relating to any machine, process, or combination in which such BeagleBoardtoys.com products or services might be or are used.

Mailing Address:

Beagleboardtoys.com
1380 Presidential Dr. #100
Richardson, TX 75081
U.S.A.



WARRANTY: *The BeagleBone DVI-D is warranted against defects in materials and workmanship for a period of 90 days from purchase. This warranty does not cover any problems occurring as a result of improper use, modifications, exposure to water, excessive voltages, abuse, or accidents. All boards will be returned via standard mail if an issue is found. If no issue is found or express return is needed, the customer will pay all shipping costs.*

Before returning the board, please visit Beagleboardtoys.com/support

To return a defective board, please request an RMA at
<http://www.beagleboardtoys.com/support/rma>

Table of Contents

FIGURES	7
TABLES	7
1.0 INTRODUCTION.....	9
2.0 CHANGE HISTORY.....	10
2.1 CHANGE HISTORY.....	10
3.0 BEAGLEBONE DVI-D CAPE OVERVIEW.....	11
4.0 BEAGLEBONE DVI-D CAPE SPECIFICATION.....	12
4.1 BEAGLEBONE DVI-D CAPE FEATURES.....	12
4.2 DVI-D INTERFACE.....	12
4.3 MECHANICAL SPECIFICATIONS	13
5.0 PRODUCT CONTENTS.....	14
5.1 BOX	14
5.2 REPAIRS	15
6.0 CONNECTIONS.....	16
6.1 HDMI CONNECTOR	16
6.2 MAIN EXPANSION HEADER	17
6.3 BATTERY EXPANSION HEADER	17
7.0 BEAGLEBONE DVI-D CAPE SYSTEM ARCHITECTURE AND DESIGN.....	19
7.1 SYSTEM BLOCK DIAGRAM.....	19
7.2 DVI-D INTERFACE.....	21
7.2.1 Main Expansion Headers	21
7.2.2 Bus Transceiver.....	21
7.2.3 Digital Transmitter.....	22
7.3 EEPROM	23
7.3.1 EEPROM Address	24
7.3.2 I2C Bus.....	24
7.4 USER LED'S	25
8.0 MECHANICAL INFORMATION.....	27
8.1 BEAGLEBONE DVI-D CAPE DIMENSIONS	27
8.2 DVI_PDN JUMPER.....	27
9.0 BEAGLEBONE DVI-D CAPE SCHEMATICS.....	28
10.0 BILLS OF MATERIAL.....	35
11.0 PCB INFORMATION	36

Figures

Figure 1.	The BeagleBone DVI-D Cape	11
Figure 2.	The BeagleBone DVI-D Cape Box.....	14
Figure 3.	BeagleBone DVI-D Cape Box Contents.....	15
Figure 4.	HDMI Connector	16
Figure 5.	Stackable Main Expansion Connector.....	17
Figure 6.	Stackable Battery Expansion Connector.....	18
Figure 7.	BeagleBone DVI-D Cape High Level Block Diagram.....	19
Figure 8.	BeagleBone DVI-D Cape Major Components	20
Figure 9.	BeagleBone DVI-D Cape Pin Usage	21
Figure 10.	Bus Transceiver	22
Figure 11.	Digital Transmitter and 2-Bit Voltage Translator.....	23
Figure 12.	BeagleBone DVI-D Cape EEPROM	24
Figure 13.	User LED's	25
Figure 14.	BeagleBone DVI-D Cape Dimensions Drawing	27

Tables

Table 1.	Change History	10
Table 2.	BeagleBone DVI-D Cape Features	12
Table 3.	User LED Control	26

NOTES



1.0 Introduction

This document is the System Reference Manual for the BeagleBone DVI-D Cape, an add-on board for the BeagleBone.

This document provides detailed information on the overall design and usage of the BeagleBone DVI-D Cape from the system level perspective. It is not intended to provide detailed documentation of any other component used on the board. It is expected that the user will refer to the appropriate documents for these devices to access detailed information. It will provide information on how to interact with these components from an interface perspective. The perspective will be general in nature and not specific to any one board.

The key sections in this document are:

[Section 2.0 – Change History](#)

Provides tracking for the changes made to the System Reference Manual.

[Section 3.0 – Overview](#)

This is a high level overview of the BeagleBone DVI-D Cape.

[Section 4.0 – Specification](#)

Provided here are the features and electrical specifications of the board.

[Section 5.0 - Product Contents](#)

Describes what the BeagleBone DVI-D Cape package looks like and what is included in the box.

[Section 6.0 – Connections](#)

Covered here is how to connect the various cables to the BeagleBone DVI-D Cape.

[Section 7.0 – System Architecture and Design](#)

This section provides information on the overall architecture and design of the BeagleBone DVI-D Cape. This is a very detailed section that goes into the design of each circuit on the board.

[Section 8.0 – Mechanical](#)

Information is provided here on the dimensions of the BeagleBone DVI-D Cape.

[Section 9.0 - Schematics](#)

These are the schematics for the BeagleBone DVI-D Cape and information on where to get the PDF and OrCAD files.

[Section 10.0 - Bills Of Material](#)

This section describes where to get the latest Bill of Material for the BeagleBone DVI-D Cape.

[Section 11.0 - PCB Information](#)

This section describes where to get the PCB file information for the BeagleBone DVI-D Cape.

2.0 Change History

2.1 Change History

Table 1 tracks the changes made for each revision of this document.

Table 1. Change History

Rev	Changes	Date	By
0.1	Initial release.	12/14/2011	BBT
0.2	1. Updated photos 2. DVI_PDn jumper	2/2/2012	BBT



3.0 BeagleBone DVI-D Cape Overview

The BeagleBone DVI-D Cape is designed to provide DVI-D interface for BeagleBone boards. This board features a standard HDMI connector, which can be connected to a DVI-D monitor using a HDMI-to-DVI-D cable. The BeagleBone DVI-D Cape is mounted on the BeagleBone via its stackable 46-pin connector.

Figure 1 below is a picture of the board.



Figure 1. The BeagleBone DVI-D Cape

4.0 BeagleBone DVI-D Cape Specification

This section covers the specifications of the BeagleBone DVI-D Cape and provides a high level description of the major components and interfaces that make up the board.

4.1 BeagleBone DVI-D Cape Features

Table 2 provides a list of the BeagleBone DVI-D Cape's features.

Table 2. BeagleBone DVI-D Cape Features

	Feature	
Interface	DVI-D	
Connector Type	HDMI	
Color Depth	RGB 16-bit	
Panel Type	Board ID EEPROM	
Power Supply	3.3V (via expansion)	
	5V (via expansion)	
PCB	2.15" x 3.40" (54.6mm x 86.4mm)	6 layers
Indicators	Power LED	
EEPROM	Board ID EEPROM	
Expansion Connector	46-pin main expansion headers	
	10-pin battery expansion header	

4.2 DVI-D Interface

The BeagleBone DVI-D Cape can drive an LCD panel equipped with a DVI-D digital input. This is the standard LCD panel interface of the processor and will support 16-bit color output. DDC2B (Display Data Channel) or EDID (Enhanced Display ID) support over I2C is provided in order to allow for the identification of the LCD monitor type and the required settings.

4.3 Mechanical Specifications

Size:	2.15" x 3.40"
Max height:	TBM
Layers:	4
PCB thickness:	.062"
RoHS Compliant:	Yes
Weight:	TBW

5.0 Product Contents

Under this section is a description of what comes in the box when the BeagleBone DVI-D Cape is purchased.

5.1 Box

The final packaged BeagleBone DVI-D Cape Rev A product will contain the following items:

- 1 box with the following items inside:
 - o 1 BeagleBone DVI-D Cape in an ESD bag
 - o 1 Reference card



Figure 2. The BeagleBone DVI-D Cape Box




Figure 3. BeagleBone DVI-D Cape Box Contents

5.2 Repairs

If you feel the board is in need of repair, follow the RMA Request process found at <http://www.beagleboardtoys.com/support/rma>

Do not send the board in for repair until a RMA authorization has been provided.

Do not return the board to the distributor unless you want to get a refund. You must get authorization from the distributor before returning the board

6.0 Connections

6.1 HDMI Connector

The BeagleBone DVI-D Cape uses an HDMI connector that was selected for smaller size. **It does not support the full HDMI interface and is used to provide the DVI-D interface portion only.** Users must use an HDMI to DVI-D cable or adapter to connect to an LCD monitor. This cable or adapter is not provided with the BeagleBone DVI-D Cape. A standard HDMI cable can be used when connecting to a monitor with an HDMI connector. **Figure 4** is a picture of the HDMI connector.

DVI-D (HDMI)
CONNECTOR




Figure 4. HDMI Connector



6.2 Main Expansion Header

The BeagleBone DVI-D Cape uses two dual row 46 position connectors. These connectors are from MLE and stackable. The part number of these connectors is SSHQ-123-D-08-F-LF. **Figure 5** is a picture of the connector.




Figure 5. Stackable Main Expansion Connector

6.3 Battery Expansion Header

This connector is a single two 10-pin expansion header. This is a dual row 10 position 2.54mm x 2.54mm connector and is the same as the main connector except with less position. **Figure 6** is a picture of the connector.




Figure 6. Stackable Battery Expansion Connector



7.0 BeagleBone DVI-D Cape System Architecture and Design

This section provides a high level description of the design of the BeagleBone DVI-D Cape and its overall architecture.

7.1 System Block Diagram

Figure 7 is the high level block diagram of the BeagleBone DVI-D Cape.




Figure 7. BeagleBone DVI-D Cape High Level Block Diagram

Figure 8 shows the location of the key components on the board.




Figure 8. BeagleBone DVI-D Cape Major Components

The information found in the remainder of this section describes in detail the architecture and design of the BeagleBone DVI-D Cape.



7.2 DVI-D Interface

7.2.1 Main Expansion Headers

The BeagleBone DVI-D Cape reserves 21 pins from the expansion headers including 16 LCD data signals, 4 LCD control signals, and a DVI power down signal. The DVI-D Cape reduces the number of LCD data signals from 24 to 16. The output quality of 16-bit color is very similar to a 24-bit; however, more signals on the expansion header can be available for other capes.

This cape uses the power rail SYS_5V to power the User LED's, EDID I2C signals to the DVI-D (HDMI) connector and the connector itself. The remaining components are powered by power rail VDD_3V3. In addition to the monitor EDID, the Board ID EEPROM on the DVI-D cape can also be accessed via I2C2 signals.

Figure 9 illustrates the number of pins dedicated for the BeagleBone DVI-D Cape.




Figure 9. BeagleBone DVI-D Cape Pin Usage

7.2.2 Bus Transceiver

LCD data and control signals are buffered through 74AVC32T245 which is a 32-bit dual supply bus transceiver. The 74AVC32T245 also features configurable voltage translation and can operate within voltage range of 1.4V-3.6V. Direction-control (DIR) and output-enable (OE) inputs determine which direction the device transmits data. LCD signals

from the main expansion headers are at 3.3V level and the buffered output from the 74AVC32T245 are also at 3.3V; thus, no voltage stepping up or down is needed. **Figure 10** shows the LCD signals buffered through 74AVC32T245.




Figure 10. Bus Transceiver

7.2.3 Digital Transmitter

TFP410 is a digital transmitter which transmits LCD signals to the HDMI port. The DVI power down signal is connected to the active-low power down pin (PD) of the transmitter. The TFP410 transmits three pairs of differential signal outputs and one pair of differential output clock to the HDMI connector. The EDID I2C signals that goes to the HDMI connector is at 5V; thus, a 2-bit bi-directional voltage translator TXS0102DCU is required to step up the EDID I2C signals from main expansion header P2 to 5V. **Figure 11** shows the TFP410 and TXS0102DCU in the schematic.





The EEPROM used on this cape is the same one as is used on the BeagleBone, a CAT24C256. The CAT24C256 is a 256 kb Serial CMOS EEPROM, internally organized as 32,768 words of 8 bits each. It features a 64-byte page write buffer and supports the

Standard (100 kHz), Fast (400 kHz) and Fast-Plus (1 MHz) I2C protocol. **Figure 12** is the design of the EEPROM circuit.




Figure 12. BeagleBone DVI-D Cape EEPROM


7.3.1 EEPROM Address

In order for each Cape to have a unique address, a board ID scheme is used that sets the address to be different depending on the order in which it is stacked onto the main board. A two position dipswitch or jumpers is used to set the address pins of the EEPROM. It is the responsibility of user to set the proper address for each board. Address line A2 is always tied high. This sets the allowable address range for the expansion cards to 0x54 to 0x57. All other I2C addresses can be used by the user in the design of their Capes. But, these addresses must not be used other than for the board EEPROM information.

7.3.2 I2C Bus

The EEPROMs on each expansion board is connected to I2C2. For this reason I2C2 must always be left connected and should not be changed by SW to remove it from the expansion header pin mux. The I2C signals require pull-up resistors. Each board must have a 5.6K resistor on these signals. With four resistors this will be an effective resistance of 1.4K if all Capes were installed.

The BeagleBone DVI-D Cape features two user LED's which are same as D2 and D3 on the BeagleBone boards. These two LED's can be access via GPIO pins on the processor. **Figure 13** shows the LED circuitry.



Q1 provides level shifting from the processor to drive the LED's that are connected to SYS_5V rail. FB8 provides noise immunity to the system by the LED's which can be a source of noise back into the system rail. Each LED is controlled by settings the appropriate GPIO bit HI. At power up all LED's are off. **Table 3** is the GPIO User LED assignments.

Table 3. User LED Control

LED	GPIO
User 0	GPIO1_21
User 1	GPIO1_22



8.0 Mechanical Information

8.1 BeagleBone DVI-D Cape Dimensions

This section provides information on the mechanical aspect of the BeagleBone DVI-D Cape. **Figure 14** is the dimensions of the BeagleBone DVI-D Cape.




Figure 14. BeagleBone DVI-D Cape Dimensions Drawing

8.2 DVI_PDn Jumper

On current BeagleBone DVI-D Cape there is a jumper connecting from pin 42 of connector P2 to R9 (which is DNI). This is the DVI_PDn signal that goes from the main connector to the DVI-D driver unit on the board. The PCBs of these boards are labeled “PCB RevA” in the back. Future releases of BeagleBone DVI-D Cape will have their PCB modified so no more jumpers are required.

9.0 BeagleBone DVI-D Cape Schematics

The following pages contain the PDF schematics for the BeagleBone DVI-D Cape. This manual will be periodically updated. The latest documentations can also be found at

http://beagleboardtoys.com/wiki/index.php?title=BeagleBone_DVID

*These design materials are ***NOT SUPPORTED*** and **DO NOT** constitute a reference design. Only “community” support is allowed via resources at BeagleBoard.org/discuss. THERE IS NO WARRANTY FOR THE DESIGN MATERIALS, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE DESIGN MATERIALS “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE DESIGN MATERIALS IS WITH YOU. SHOULD THE DESIGN MATERIALS PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.*

We mean it, these design materials may be totally unsuitable for any purposes.

REV	DATE	BY	CHANGE
A	11/22/2011	BRT	Initial release.

This work is licensed under the Creative Commons Attribution-Share Alike 3.0 Unported License. To view a copy of this license, visit <http://creativecommons.org/licenses/by-sa/3.0/> or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA.

All derivative works are to be attributed to CircuitCo LLC.

For more information, see <http://creativecommons.org/licenses/by-sa>

This work is licensed under the Creative Commons Attribution-Share Alike 3.0 Unported License. All derivative works are to be attributed to CircuitCo LLC.


beagleboardtoys.com

1380 Presidential Dr.
#100
Richardson, TX 75081
www.beagleboardtoys.com


BeagleBone DVI-D Cape COVER PAGE


Document Number
Rev. C
1380-001
11/22/2011


Page 1 of 8

















10.0 Bills of Material

The Bill of Material for the BeagleBone DVI-D Cape is provided at beagleboardtoys.com at the following location:

http://beagleboardtoys.com/wiki/index.php?title=BeagleBone_DVID

*These design materials are ***NOT SUPPORTED*** and **DO NOT** constitute a reference design. Only “community” support is allowed via resources at BeagleBoard.org/discuss. THERE IS NO WARRANTY FOR THE DESIGN MATERIALS, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE DESIGN MATERIALS “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE DESIGN MATERIALS IS WITH YOU. SHOULD THE DESIGN MATERIALS PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.*

We mean it, these design materials may be totally unsuitable for any purposes.

11.0 PCB Information

Gerber files and Allegro source files are available on beagleboardtoys.com at the following address:

http://beagleboardtoys.com/wiki/index.php?title=BeagleBone_DVID

*These design materials are ***NOT SUPPORTED*** and **DO NOT** constitute a reference design. Only “community” support is allowed via resources at BeagleBoard.org/discuss. THERE IS NO WARRANTY FOR THE DESIGN MATERIALS, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE DESIGN MATERIALS “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE DESIGN MATERIALS IS WITH YOU. SHOULD THE DESIGN MATERIALS PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.*

We mean it, these design materials may be totally unsuitable for any purposes.