


Metabolome PCA biplot

TIC -> log2(x+1); prcomp(center=TRUE, scale=TRUE)



Top 20 PCA loadings (PC1/PC2 strength)

Zoomed in view (axis does not start at 0)

