



# Rear Steering Gearbox

## Illustrated Index

### CAUTION:

1. Do not apply torque of more than 0.1 kg-m (0.72 lb-ft) to the offset shaft.
2. Do not strike the stroke rod.
3. Never loosen the offset shaft screw and lock nut screw.
4. Do not remove the gearbox cover.
5. Use the special tool "Rear Steering Gearbox Center Lock Pin" when removing the rear steering gearbox, and leave it intact except when the gearbox is inspected for function, etc.
6. Also use the special tool "Rear Steering Gearbox Center Lock Pin" when removing the front or rear of the center shaft.

