

Timing Belt

Positioning Crankshaft Before Installing Timing Belt

NOTE: Install the timing belt with the No. 1 piston at TDC (Top Dead Center) of the compression stroke.

MANUAL TRANSMISSION:

POINTER ON
CRANKCASE

TDC MARK
(Painted White)

AUTOMATIC TRANSMISSION:

POINTER ON
CRANKCASE

TDC MARK
(Painted White)

Timing mark aligned with the
valve cover surface.

DIRECTION OF ROTATION

With engine installed, turn
crank with socket wrench
and extension as shown.